

KitchenAid

WATER KETTLE 5KEK1701B, 5KEK1701E PRODUCT GUIDE



W11659147A

PARTS AND FEATURES



1. Lid Open Button

2. Lid

3. Water Window

4. Power Button

5. Base
6. Temperature Selector Lever

7. Underside Base with Power Cord

8. Water Kettle

9. Filter

PRODUCT SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

! DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

! WARNING

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions. Misuse of appliance may result in personal injury.
2. Do not touch hot surfaces. Use handles.
3. To protect against fire, electrical shock and injury to persons do not immerse Base, cord, plug, or Water Kettle in water or other liquids.
4. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

5. **European Union Only:** This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.
6. The Kettle is only to be used with the stand provided.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.
9. Close supervision is necessary when any appliance is used by or near children.
10. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest Authorised Service Centre for examination, repair, or electrical or mechanical adjustment.
11. The use of attachments/accessories not recommended or sold by KitchenAid may cause fire, electrical shock, or injury to persons.
12. Do not use the appliance outdoors.
13. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
14. Do not let the cord hang over the edge of table or counter, or touch hot surfaces.
15. Do not place on or near a hot gas or electric burner or in a heated oven.
16. Do not use appliance without Lid properly closed.
17. Do not use the appliance with loose or weakened handle.
18. **WARNING:** Do not remove the Lid while the water is boiling.
19. **CAUTION:** Insure that the appliance is switched off before removing from its stand.
20. Never pour water on hot or burning fat.

21. Do not use the appliance for other than intended use.
22. Do not clean Kettle with cleaners, steel wool, or other abrasive materials. To prevent damage to the appliance do not use alkaline cleaning agents when cleaning; use a soft cloth and a mild detergent.
23. **CAUTION:** Do not operate the Kettle on an inclined plane. Do not operate the Kettle unless the element is fully immersed. Do not move while the Kettle is switched ON.
24. The Kettle should only be used to heat water.
25. Do not overfill Kettle. If the Kettle is overfilled, boiling water may be ejected.
26. Unplug the appliance from outlet when not in use and before cleaning.
27. Allow the appliance to cool completely before putting on or taking off parts, and before cleaning the appliance.
28. Refer to the "Care and Cleaning" section for instructions on cleaning the surfaces in contact with food.
29. Scalding may occur if the Lid is removed during the brewing cycle.
30. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farmhouses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.

SAVE THESE INSTRUCTIONS

For complete details on product information, instructions and videos, including Guarantee information, visit

www.KitchenAid.co.uk or **www.KitchenAid.eu**. This may save you the cost of a service call. To receive a free printed copy of the information online, call **00 800 381 040 26**.

ELECTRICAL REQUIREMENTS

WARNING

Electrical Shock Hazard



Plug into an earthed outlet.

Do not remove earth prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Power: 2500-3000 W for 5KEK1701B
2000-2400 W for 5KEK1701E

Voltage: 220-240 VAC

Frequency: 50-60 Hz

NOTE: The Water Kettle has a earthed plug. To reduce the risk of electrical shock, this plug will fit in an outlet only one way. If the plug does not fit in the outlet, contact a qualified electrician. Do not modify the plug in any way.


Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or serviceman install an outlet near the appliance. A short power supply cord (or detachable power supply cord) should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power supply cords or extension cords are available and may be used.

If a longer detachable power supply cord or extension cord is used:


- The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
- If the appliance is of the earthed type, the extension cord should be a earthed type 3-wire cord.
- The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

INSERTING AND REMOVING THE FILTER

Inserting the Filter: The Filter is located behind the spout inside the Water Kettle. Open the Lid. Slide the Filter down into the slot behind the spout.



Removing the Filter: Open the Lid. Grasp the top of the Filter, behind the spout, and pull out to remove.



PRODUCT USAGE

BEFORE FIRST USE

Before first use, fill the Water Kettle to the maximum level, then boil and discard the water.


IMPORTANT: The Water Kettle is designed for water only. Do not put any other liquids or substances in the Water Kettle.

FILLING THE WATER KETTLE


1. Open the Lid of the Water Kettle by pressing the Lid Open Button.




2. Fill the Water Kettle. There must be a minimum of 0.5 L to operate.



3. Push the Lid down until it locks into place. You will hear a clicking sound which indicates the Lid is locked.



4. Place the Water Kettle on the Base.




SETTING THE WATER TEMPERATURE

1. Slide the Temperature Selector Lever on the Base to the desired setting (50-100°C).



2. Press Power Button (⏻) on the side of the Base. The controls will light up and the Water Kettle will begin to heat.



NOTE: The Water Kettle will stop automatically once the set temperature is reached. The heating cycle can also be turned off manually by pressing Power Button (⏻).


WATER TEMPERATURE GUIDE FOR BEST RESULTS

Use this guide for outstanding results from your KitchenAid Water Kettle.


60°C/140°F	70°C/158°F	80°C/176°F	90°C/194°F	100°C/212°F
Delicate Tea	Green Tea Gyokuro Sencha	Blooming Tea	Black Tea Earl Grey English Breakfast	Boil Water
		Chai Green White		Chai Red
	White Tea Silver Needle	Green Tea Bencha Genmaicha	Oolong Tea	Herbal Tea Tisanes
			Hot Chocolate	Instant Soup
			Instant Coffee	Oatmeal
				Rooibos Tea
				Yerba Maté

The Water Kettle can be turned off in several ways:

1. Press Power Button (⏻) while in heating mode.



2. Unplug cord when Water Kettle is not in use.




CARE AND CLEANING

IMPORTANT: Allow the appliance to cool completely before putting on or taking off parts, and before cleaning the appliance.

CLEANING THE WATER KETTLE AND BASE


IMPORTANT: Before cleaning, always disconnect the Water Kettle from electrical outlet and make sure that the Water Kettle has cooled completely.

Wash Water Kettle and Base by hand with a damp cloth. Dry and polish with a soft cloth. Abrasives and scouring agents of any kind are not recommended.



CLEANING THE FILTER

1. Remove Filter from Water Kettle (see "Inserting and Removing the Filter" section); then rinse under running water.



2. Clean under hot water with a soft brush or cloth to remove deposits, and replace Filter by sliding the Filter into the slot behind the spout.




NOTE: If calcium deposits remain on the Filter, let it stand overnight in a solution of water and white vinegar. Rinse the Filter thoroughly and replace in the Water Kettle.

DESCALING THE WATER KETTLE

Calcium deposits may form on the interior metal parts of the Water Kettle. To get the best performance from the Water Kettle, clean periodically. The cleaning interval will depend on the hardness of the water put into the Water Kettle. The use of a commercial descaler is recommended.


If a commercial descaler is not available:

1. Fill the Water Kettle with white vinegar to the Minimum 0.5 L mark.




A. Vinegar
B. Water

2. Add water to 1 L.
3. Boil and allow to stand overnight.
4. Empty the solution from the Water Kettle.



5. Fill the Water Kettle with water, bring to a boil and drain out the water. Repeat this step twice. The Water Kettle is now ready to use.



ELECTRICAL EQUIPMENT WASTE DISPOSAL

DISPOSAL OF PACKING MATERIAL

The packing material is recyclable and is marked with the recycle symbol . The various parts of the packing must therefore be disposed of responsibly and in full compliance with local authority regulations governing waste disposal.

RECYCLING THE PRODUCT

- This appliance is marked in compliance with law in the EU and UK covering, Waste Electrical and Electronic Equipment (WEEE).
- By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.
- The symbol  on the product or on the accompanying documentation indicates that it should not be treated as domestic waste but must be taken to an appropriate collection centre for the recycling of electrical and electronic equipment.

For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

DECLARATION OF CONFORMITY

FOR UNITED KINGDOM

This appliance has been designed, constructed and distributed in compliance with the safety requirements of UK Legislation: Electrical Equipment (Safety) Regulations 2016, Electromagnetic Compatibility Regulations 2016. The Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2019. The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.

FOR EUROPEAN UNION

This appliance has been designed, constructed, and distributed in compliance with the safety requirements of EC Directives: Low Voltage Directive 2014/35/EU, Electromagnetic Compatibility Directive 2014/30/EU, Directive 92/42/EEC Hot Water Boilers, Ecodesign Directive 2009/125/EC, RoHS Directive 2011/65/EU and following amendments.

TERMS OF KITCHENAID GUARANTEE ("GUARANTEE")

Covering U.K. - Ireland - UAE

KitchenAid Europa, Inc., Nijverheidslaan 3, Box 5, 1853 Strombeek-Bever, Belgium ("Guarantor") grants the end-customer, who is a consumer, a Guarantee pursuant to the following terms.

FOR U.K.:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product. In summary, the Consumer Rights Act 2015 says products must be as described, fit for purpose and of satisfactory quality. During the expected lifespan of your product your legal rights entitle you to the following:

- Up to 30 days: if your product is faulty, then you can get an immediate refund.
- Up to six months: if your product can't be repaired or replaced, then you're entitled to a full refund, in most cases.
- Up to six years: if your product does not last a reasonable length of time you may be entitled to some money back.

These rights are subject to certain exceptions. For detailed information please visit the Citizens Advice website www.adviceguide.org.uk or call 03454 04 05 06.

FOR IRELAND:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product under the European Communities (Certain Aspects of the Sale of Consumer Goods and Associated Guarantees Regulations 2003 (S.I. No. 11/2003)) and other enactments governing the sale of consumer goods.

FOR UAE:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product.

1. SCOPE AND TERMS OF THE GUARANTEE

- a) The Guarantor grants the Guarantee for the products mentioned under Section 1.b) which a consumer has purchased from a seller or a company of the KitchenAid-Group within the following countries: U.K., Ireland, or the United Arab Emirates (UAE).
- b) The Guarantee period depends on the purchased product and is as follows:

One Year full guarantee from date of purchase.
- c) The Guarantee period commences on the date of purchase, i.e. the date on which a consumer purchased the product from a dealer or a company of the KitchenAid-Group.
- d) The Guarantee covers the defect-free nature of the product.
- e) The Guarantor shall provide the consumer with the following services under this Guarantee, at the choice of the Guarantor, if a defect occurs during the Guarantee period:
 - Repair of the defective product or product part, or
 - Replacement of the defective product or product part. If a product is no longer available, the Guarantor is entitled to exchange the product for a product of equal or higher value.
- f) If the consumer wishes to make a claim under the Guarantee, the consumer has to contact the country specific KitchenAid service centres or the Guarantor directly at KitchenAid Europa, Inc. Nijverheidslaan 3, Box 5, 1853 Strombeek-Bever, Belgium;

Email-Address U.K.: CONSUMERCARE.UK@kitchenaid.eu

Email-Address IRELAND: CONSUMERCARE.IE@kitchenaid.eu

Toll Free Number U.K. & IRELAND: **00 800 381 040 26**

FOR UAE:

AL GHANDI ELECTRONICS.

POST BOX NO. 9098,

DUBAI, UNITED ARAB EMIRATES

Toll free number: +971 4 2570007

- g) The costs of repair, including spare parts, and any postage costs (if applicable) for the delivery of a defect-free product or product part shall be borne by the Guarantor. The Guarantor shall also bear the postage costs for returning the defective product or product part if the Guarantor or the country specific KitchenAid customer service centre requested the return of the defective product or product part. However, the consumer shall bear the costs of appropriate packaging for the return of the defective product or product part.
- h) To be able to make a claim under the Guarantee, the consumer must present the receipt or invoice of the purchase of the product.

2. LIMITATIONS OF THE GUARANTEE

- a) The Guarantee applies only to products used for private purposes and not for professional or commercial purposes.
- b) The Guarantee does not apply in the case of normal wear and tear, improper or abusive use, failure to follow the instructions for use, use of the product at the wrong electrical voltage, installation and operation in violation of the applicable electrical regulations, and use of force (e.g. blows).
- c) The Guarantee does not apply if the product has been modified or converted, e.g. conversions from 120 V products to 220-240 V products.
- d) The provision of Guarantee services does not extend the Guarantee period, nor does it initiate the commencement of a new Guarantee period. The Guarantee period for installed spare parts ends with the Guarantee period for the entire product.
- e) **FOR UAE ONLY:**
Further or other claims, in particular claims for damages, are excluded unless liability is mandatory by law.

After expiry of the Guarantee period or for products for which the Guarantee does not apply, the KitchenAid customer service centres are still available to the end-customer for questions and information.

Further information is also available on our website:

■ For U.K. & Ireland www.kitchenaid.eu

■ For UAE: www.KitchenAid-MEA.com

PRODUCT REGISTRATION

Register your new KitchenAid appliance now: <http://www.kitchenaid.eu/register>