

Digital Still Camera

Instruction Manual

Cyber-shot

DSC-W810

English

Learning more about the camera ("Help Guide")



"Help Guide" is an on-line manual. Refer to it for in-depth instructions on the many functions of the camera.

- ① Access the Sony support page.
<http://www.sony.net/Sonyinfo/Support/>
- ② Select your country or region.
- ③ Search for the model name of your camera within the support page.
 - Check the model name on the bottom of your camera.

Checking the supplied items

- The number in parentheses indicates the number of pieces.
- Camera (1)
 - Rechargeable battery pack NP-BN (1) (This rechargeable battery pack cannot be used with Cyber-shot™ that are supplied with the NP-BN1 battery pack.)
 - Dedicated USB cable (1)
 - AC Adaptor AC-UB10C (1)
 - Power cord (mains lead) (not supplied in the USA and Canada) (1)
 - Wrist strap (1)
 - Instruction Manual (this manual) (1)


- Trademarks**
- Memory Stick and  are trademarks or registered trademarks of Sony Corporation.
 - Microsoft, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
 - Mac, Mac OS are registered trademarks of Apple Inc.
 - Intel, Pentium, and Intel Core are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.
 - SDXC logo is a trademark of SD-3C, LLC.
 - Facebook and the "f" logo are trademarks or registered trademarks of Facebook, Inc.
 - YouTube and the YouTube logo are trademarks or registered trademarks of Google Inc.
 - In addition, system and product names used in this manual are, in general, trademarks or registered trademarks of their respective developers or manufacturers.
 - However, the ™ or ® marks may not be described in this manual.

Additional information on this product and answers to frequently asked questions can be found at our Customer Support Website.

<http://www.sony.net/>

How to use

Inserting the battery pack




- 1 Open the cover.
- 2 Insert the battery pack.


Charging the battery pack


Turn off the camera while charging the battery.

For customers in USA and Canada



For customers in countries/regions other than the USA and Canada





- 1 Connect the camera to the AC Adaptor (supplied), using the dedicated USB cable (supplied).
- 2 Connect the AC Adaptor to the wall outlet.


• Be sure to use only genuine Sony brand battery packs, the dedicated USB cable (supplied) and AC Adaptor (supplied).

Charging time (Full charge)

The charging time is approximately 115 min., using the AC Adaptor (supplied).

To charge by connecting to a computer

The battery pack can be charged by connecting the camera to a computer using the dedicated USB cable.




Battery life and number of images that can be recorded and played back

	Total usage time	Number of images
Shooting (still images)	Approx. 100 min.	Approx. 200 images
Actual shooting (movies)	Approx. 30 min.	—
Continuous shooting (movies)	Approx. 100 min.	—
Viewing (still images)	Approx. 180 min.	Approx. 3600 images

• The number is based on the CIPA standard.
(CIPA: Camera & Imaging Products Association)

Inserting a memory card (sold separately)




- 1 Open the cover.
- 2 Insert the memory card (sold separately).

To remove the memory card/battery pack

Memory card: Push the memory card in once to eject the memory card.
Battery pack: Slide the battery eject lever. Be sure not to drop the battery pack.

Setting the clock




- 1 Press the ON/OFF (Power) button.
- 2 Select a desired language.
- 3 Select a desired geographic location by following the on screen instructions, then press ● on the control button.
- 4 Set [Date & Time Format], [Summer Time] and [Date & Time], then select [OK].
- 5 Follow the instructions on the screen.

To set the date and time again

Select MENU →  (Settings) →  (Clock Settings) → [Date & Time Setting] to open the date & time setting display.

Shooting still images/movies




Shooting still images

- 1 Press the shutter button halfway down to focus.
- 2 Press the shutter button fully down to shoot an image.

Shooting movies

- 1 Press the MOVIE (Movie) button to start recording.
- 2 Press the MOVIE (Movie) button again to stop recording.

Viewing images



- 1 Press  (Playback) on the control button.

To select next/previous image

Select an image by pressing ▶ (next)/◀ (previous) on the control button. Press ● in the center of the control button to view movies.

To delete an image

- ① Press  (Delete) on the control button.
- ② Select [This Image] with ▲ on the control button, then press ●.

Features of PlayMemories Home™



Importing images from your camera

You can use the following functions with Windows computers.



Viewing images on Calendar



Uploading images to network services

Playing back images imported from your camera.



Sharing images on PlayMemories Online™



PlayMemories

Downloading PlayMemories Home

You can download PlayMemories Home from the following URL:
www.sony.net/pm/

• For details on applications for Mac computers, visit the following URL:
<http://www.sony.co.jp/imsoft/Mac/>

Recommended computer environment

You can check the system requirements for software at the following URL:
www.sony.net/pcenv/



Notes on using the camera

On use and care

Avoid rough handling, disassembling, modifying, physical shock, or impact such as hammering, dropping, or stepping on the product. Be particularly careful of the lens.

On database files

When you insert a memory card without a database file into the camera and turn on the power, part of the memory card capacity is used to automatically create a database file. It may take some time until you can perform the next operation. If a database file error occurs, import all the images to a computer using PlayMemories Home, then format the memory card.

Notes on recording/playback

- To ensure stable operation of the memory card, we recommend that you use this camera to format any memory card being used with this camera for the first time. Note that formatting will erase all data recorded on the memory card. This data cannot be restored. Be sure to back up any important data to a computer or other storage location.
- Before you start recording, make a trial recording to make sure that the camera is working correctly.

- The camera is neither dust-proof, nor splash-proof, nor water-proof.
- Avoid exposing the camera to water. If water enters inside the camera, a malfunction may occur. In some cases, the camera cannot be repaired.
- Do not aim the camera at the sun or other bright light. It may cause the malfunction of the camera.
- Do not use the camera near a location that generates strong radio waves or emits radiation. Otherwise, the camera may not properly record or play back images.
- Using the camera in sandy or dusty locations may cause malfunctions.
- Do not shake or strike the camera. It may cause a malfunction and you may not be able to record images. Furthermore, the recording media may become unusable or image data may be damaged.
- Clean the flash surface before use. The heat of the flash emission may cause dirt on the flash surface to start smoking or burning. Wipe the flash surface with a soft cloth to remove dirt or dust, etc.

On camera's temperature

Your camera and battery may get hot due to continuous use, but it is not a malfunction.

On the overheat protection

Depending on the camera and battery temperature, you may be unable to record movies or the power may turn off automatically to protect the camera. A message will be displayed on the screen before the power turns off or you can no longer record movies. In this case, leave the power off and wait until the camera and battery temperature goes down. If you turn on the power without letting the camera and battery cool enough, the power may turn off again or you may be unable to record movies.

Warning on copyright

Television programs, films, videotapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provisions of the copyright laws.

No compensation for damaged content or recording failure

Sony cannot compensate for failure to record or loss or damage of recorded content due to a malfunction of the camera or recording media, etc.

On moisture condensation

If the camera is brought directly from a cold to a warm location, moisture may condense inside or outside the camera. This moisture condensation may cause a malfunction of the camera.

If moisture condensation occurs

Turn off the camera and wait about an hour for the moisture to evaporate. Note that if you attempt to shoot with moisture remaining inside the lens, you will be unable to record clear images.

How to store the battery pack

To prevent staining the terminal, short-circuiting, etc., be sure to use a plastic bag, etc. to keep away from metal materials when carrying or storing.

Specifications

Camera

[System]

Image device: 7.76 mm (1/2.3 type) CCD, Primary color filter
Total pixel number of camera: Approx. 20.4 megapixels
Effective pixel number of camera: Approx. 20.1 megapixels
Lens: 6x zoom lens

f = 4.6mm – 27.6 mm (26 mm – 156 mm [35 mm film equivalent])
F3.5 (W) – F6.5 (T)
While shooting movies (16:9): 32 mm – 189 mm
While shooting movies (4:3): 26 mm – 156 mm

SteadyShot: Electronic
Burst shooting (when shooting with the largest pixel number):
Approx. 0.52 image/second (up to 100 images)

File format:
Still images: JPEG (DCF, Exif, MPF Baseline) compliant, DPOF compatible
Movies: AVI (Motion JPEG)

Recording media: Internal Memory (Approx. 29 MB), Memory Stick PRO Duo™ media, Memory Stick Micro™ media, SD cards, microSD memory cards

Flash: Flash range (ISO sensitivity (Recommended Exposure Index) set to Auto):
Approx. 0.4 m to 3.2 m (1.3 ft to 10.4 ft) (W)
Approx. 1 m to 1.74 m (3.25 ft to 5.65 ft) (T)

[Input and Output connectors]

USB / A/V OUT jack:
Video output
Audio output
USB communication
USB communication: Hi-Speed USB (USB 2.0)

[Screen]

LCD screen: 6.7 cm (2.7 type) TFT drive
Total number of dots: 230 400 dots

[Power, general]

Power: Rechargeable battery pack NP-BN, 3.6 V
AC Adaptor AC-UB10C, 5 V
Power consumption (during shooting): Approx. 1.0 W
Operating temperature: 0 °C to 40 °C (32 °F to 104 °F)
Storage temperature: –20 °C to +60 °C (–4 °F to +140 °F)
Dimensions (CIPA compliant):
96.8 mm × 55.5 mm × 20.9 mm (3 7/8 in x 2 1/4 in x 7/32 in) (W/H/D)

Mass (CIPA compliant) (including NP-BN battery pack, Memory Stick PRO Duo media):
Approx. 127 g (4.5 oz)
Microphone: Monaural
Speaker: Monaural
Exif Print: Compatible
PRINT Image Matching III: Compatible
AC Adaptor AC-UB10C
Power requirements: AC 100 V to 240 V, 50 Hz/60 Hz, 70 mA
Output voltage: DC 5 V, 0.5 A
Operating temperature: 0 °C to 40 °C (32 °F to 104 °F)
Storage temperature: –20 °C to +60 °C (–4 °F to +140 °F)
Dimensions:
Approx. 50 mm × 22 mm × 54 mm (2 inches × 7/8 inches × 2 1/4 inches) (W/H/D)

Rechargeable battery pack NP-BN

Battery type: Lithium-ion battery
Maximum voltage: DC 4.2 V
Nominal voltage: DC 3.6 V
Maximum charge voltage: DC 4.2 V
Maximum charge current: 0.9 A
Capacity:
typical: 2.3 Wh (630 mAh)
minimum: 2.2 Wh (600 mAh)

Design and specifications are subject to change without notice.

Owner's Record

The model and serial numbers are located on the bottom. Record the serial number in the space provided below. Refer to these numbers whenever you call your Sony dealer regarding this product.
Model No. DSC-W810
Serial No. _____
Model No. AC-UB10C
Serial No. _____

WARNING

To reduce fire or shock hazard, do not expose the unit to rain or moisture.

IMPORTANT SAFETY INSTRUCTIONS
-SAVE THESE INSTRUCTIONS
DANGER
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

If the shape of the plug does not fit the power outlet, use an attachment plug adaptor of the proper configuration for the power outlet.

CAUTION

Battery pack

- If the battery pack is mishandled, the battery pack can burst, cause a fire or even chemical burns.
- Observe the following cautions.
- Do not disassemble.
 - Do not crush and do not expose the battery pack to any shock or force such as hammering, dropping or stepping on it.
 - Do not short circuit and do not allow metal objects to come into contact with the battery terminals.
 - Do not expose to high temperature above 60°C (140°F) such as in direct sunlight or in a car parked in the sun.
 - Do not incinerate or dispose of in fire.
 - Do not handle damaged or leaking lithium ion batteries.
 - Be sure to charge the battery pack using a genuine Sony battery charger or a device that can charge the battery pack.
 - Keep the battery pack out of the reach of small children.
 - Keep the battery pack dry.
 - Replace only with the same or equivalent type recommended by Sony.
 - Dispose of used battery packs promptly as described in the instructions.

AC Adaptor

Use the nearby wall outlet (wall socket) when using the AC Adaptor. Disconnect the AC Adaptor from the wall outlet (wall socket) immediately if any malfunction occurs while using the apparatus.

For Customers in Europe

Notice for the customers in the countries applying EU Directives

Manufacturer: Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan
For EU product compliance: Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany


Notice

If static electricity or electromagnetism causes data transfer to discontinue midway (fail), restart the application or disconnect and connect the communication cable (USB, etc.) again.

This product has been tested and found compliant with the limits set out in the EMC regulation for using connection cables shorter than 3 meters (9.8 feet).


The electromagnetic fields at the specific frequencies may influence the picture and sound of this unit.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Disposal of waste batteries (applicable in the European Union and other European countries with separate collection systems)



By ensuring these batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of the battery. The recycling of the materials will help to conserve natural resources.

In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only.

To ensure that the battery will be treated properly, hand over the product at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment.
For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries.

For more detailed information about recycling of this product or battery, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.