

Quick start guide









Step A *Connect*

Step B *Setup*

Step C *Enjoy*

What's in the Box?

You should find these items upon opening the box.



PHILIPS

Step A *Connect*

Attach the supplied stands to the main unit and speakers respectively so that they can stand firmly on a desktop.


Connect the speaker cables.

Connect the AM and FM antennas.

Connect the power cable of the system.

- See the *User Manual* for how to connect other equipment to this system.

- See **Wall Mounting** for detailed instructions if you want to mount the system on the wall.



Step B *Setup*


Setting the clock

In active mode, press **CLOCK•TIMER** (**CLOCK** on the remote) repeatedly until the time digits flash.

Press **ALBUM-/+** **◀▶** (**◀▶** on the remote) repeatedly to set the hour.

Press **TITLE +/-** **◀ / ▶** (**ALBUM/PRESET +/-** on the remote) repeatedly to set the minute.

Press **CLOCK•TIMER** (**CLOCK** on the remote) again to store the setting.



Playing a disc

1

Press **LEFT OPEN • CLOSE** or **RIGHT OPEN • CLOSE** on the front panel (L  or R  on the remote) to open the left or right CD door respectively.

2

Insert one or more discs with the printed side facing you. Press **LEFT OPEN • CLOSE** or **RIGHT OPEN • CLOSE** on the front panel (L  or R  on the remote) again to close the CD door.


3

Use **DISC 1/2/3/4** (or **CD 1/2/3/4** on the remote control) to select a disc for playback.

→ Playback will start automatically. If not press .

4

To stop playback, press .



Programming and tuning to radio stations

1


Press **SOURCE** on the front panel of the system repeatedly or **TUNER** on the remote to select the tuner source.

2

Press **PROGRAM** for more than two seconds to program all available stations in order of waveband.

3

Press **TITLE +/-**   (**ALBUM/PRESET +/-** on the remote) until the desired preset station is displayed.



Tip

Detailed playback features and additional functions are described in the accompany owner's manual.

