

Register your product and get support at
www.philips.com/welcome

GoGear

SA018102

SA018104



EN User manual

PHILIPS

Contents

1	Important safety information	2
	General maintenance	2
	Recycling the product	3
2	Your new SA018	6
	What's in the box	6
3	Getting started	7
	General overview of SA018	7
	Detailed overview of the controls	7
	Status indicators and their meanings	9
	Connect and charge	11
	Connect the supplied USB cable	11
	Connect the earphones	11
	Install the Philips Device Manager software	11
	Transfer music to SA018	12
	Organize your music on SA018	12
4	Enjoy	13
	Turn SA018 on and off	13
	Automatic shut-down	13
	Listen to your music	13
	Listen to FM radio	14
5	Use SA018 to carry files	16
6	Troubleshooting	17
7	Technical data	18
	Supported music file formats	18
8	Glossary	19

Need help?

Please visit

www.philips.com/welcome

where you can access a full set of supporting materials such as the user manual, the latest software updates, and answers to frequently asked questions.

1 Important safety information

General maintenance

Caution

- To avoid damage or malfunction:
- Do not expose the product to excessive heat caused by heating equipment or direct sunlight.
- Do not drop the product or allow objects to fall on your player.
- Do not allow the product to be submerged in water. Do not expose headphone socket or battery compartment to water, as water entering the set may cause major damage.
- Active mobile phones in the vicinity may cause interference.
- Back up your files. Ensure that you retain the original files you have downloaded to your device. Philips is not responsible for any loss of data if the product becomes damaged or not readable / legible.
- Manage (transfer, delete, etc.) your music files only with the supplied music software to avoid problems.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as these may harm the product.

About operating and storage temperatures

- Operate in a place where temperature is always between 0 and 35°C (32 to 95°F)
- Store in a place where temperature is always between -20 and 45°C (-4 to 113°F).
- Battery life may be shortened in low temperature conditions.

Replacement parts/accessories:

Visit www.philips.com/support to order replacement parts/accessories.

Hearing Safety



Listen at a moderate volume:

Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.

Sound can be deceiving. Over time your hearing 'comfort level' adapts to higher volumes of sound. So after prolonged listening, what sounds 'normal' can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.

To establish a safe volume level:

Set your volume control at a low setting.

Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

Prolonged exposure to sound, even at normally 'safe' levels, can also cause hearing loss.

Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones.

Listen at reasonable volumes for reasonable periods of time.

Be careful not to adjust the volume as your hearing adapts.

Do not turn up the volume so high that you can't hear what's around you.

You should use caution or temporarily discontinue use in potentially hazardous situations.

Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.

Modifications

Modifications not authorized by the manufacturer may void user's authority to operate the product.

Copyright information

All other brands and product names are trademarks of their respective companies or organizations.

Unauthorized duplication of any recordings whether downloaded from the Internet or made from audio CDs is a violation of copyright laws and international treaties.

The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

The Windows Media and the Windows logo are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Be responsible! Respect copyrights.



**Be responsible
Respect copyrights**

Philips respects the intellectual property of others, and we ask our users to do the same.

Multimedia content on the internet may have been created and/or distributed without the original copyright owner's authorization.

Copying or distributing unauthorized content may violate copyright laws in various countries including yours.

Compliance with copyright laws remains your responsibility.

The recording and transfer to the portable player of video streams downloaded to your computer is intended only for use with public domain or properly licensed content. You may only use such content for your private, non-commercial use and shall respect eventual copyright instructions provided by the copyright owner of the work. Such instruction may

state that no further copies shall be made. Video streams may include copy protection technology that prohibits further copying. For such situations the recording function will not work and you will be notified with a message.

Data logging

Philips is committed to improving the quality of your product and enhancing the Philips user experience. To understand the usage profile of this device, this device logs some info / data to the non-volatile memory region of the device. These data are used to identify and detect any failures or problems you as a user may experience while using the device. The data stored, for example, will be the duration of playback in music mode, duration of playback in tuner mode, how many times battery low was encountered, etc. The data stored do not reveal the content or media used on the device or the source of downloads. The data stored on the device are retrieved and used ONLY if the user returns the device to the Philips service center and ONLY to simplify error detection and prevention. The data stored shall be made available to user on user's first request.

Recycling the product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

 **Caution**



- Removal of the built-in battery invalidates the warranty and may destroy the product. The following instructions are disposal instructions at the end of product life.

Your product contains a built-in rechargeable battery covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.



Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

To safeguard the functionality and safety of your product, take your product to an official collection point or service centre where a professional can remove or replace the battery as shown:



Notice for the European Union

This product complies with the radio interference requirements of the European Union.

Notice for the USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Notice for Canada

This Class B digital apparatus complies with Canadian ICES-003.

The set complies with the FCC-Rules, Part-15 and with 21 CFR 1040.10. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

2 Your new SA018

SA018 allows you to

- play MP3 and unprotected WMA files
- listen to FM radio

What's in the box

SA018 comes with a box that you can use to store the product or other items.

The following accessories are included with SA018:

Player



Earphones



USB cable




Quick start guide



3 Getting started

General overview of SA018



1	 / 	combined headphone / USB connection jack
2	- VOL +	press: increase/decrease the volume press and hold: increase/decrease fast
3	 / 	press: skip to next / previous track double press: skip to next / previous folder press and hold: scan forwards / backwards within current track
4		press: play/pause
5	RESET	press: reset SA018
6	FM /  / 	slide: select source/mode
7		slide: lock/unlock all buttons

8  press and hold: turn SA018 on/off

Note

- When SA018 is switched off, it consumes little or no power. All controls except the on/off control are disabled in 'off' mode. For reasons of power conservation, it may take a moment to turn on SA018.

Detailed overview of the controls

SA018 offers the following control options:
Mode  / 

Function	Action
	Press 1x: toggle between play and pause Press and hold: go to beginning of first track on SA018
	Press 1x at the beginning of a track: go to beginning of previous track Press 1x when playing: go to beginning of current track Press and hold when playing: scan backwards through current track Press 2x: skip to previous folder (if folders are present)
	Press 1x: go to beginning of next track Press and hold when playing: scan forward through current track Press 2x: skip to next folder (if folders are present)
- VOL +	Press 1x: increase / decrease the volume one step at a time Press and hold: quickly increase / decrease the volume Press and hold both buttons simultaneously: toggle FullSound™ on / off
	Press and hold for 4 seconds: toggle SA018 on / off

Mode **FM**:

Function	Action
	Press 1x: toggle the radio sound between mute and unmute Press and hold: save current frequency to preset
	Press 1x: skip to next lower frequency Press 2x: skip to previous preset (if presets are present) Press and hold: quickly scan downwards to next stronger frequency
	Press 1x: skip to next higher frequency Press 2x: skip to next preset (if presets are present) Press and hold: quickly scan upwards to next stronger frequency
	Press 1x: increase / decrease the volume one step at a time Press and hold: quickly increase / decrease the volume
	Press and hold for 4 seconds: toggle SA018 on / off

 Note

- In idle mode, SA018 turns off when no button is pressed for 5 minutes.

Source slide selector**FM** / /

FM		
Select FM radio source	Select music source repeat all mode	Select music source shuffle* mode

* In shuffle mode, SA018 plays the tracks in random order.

Status indicators and their meanings

LED indicators:

Action	Control	LED indicator
slide	- FM (FM radio mode) -  (repeat mode) -  (shuffle mode)	 (= ok)
press	-  (play) -  (back) -  (forward) - Vol+ (increase volume) - Vol- (decrease volume)	 (= ok) - LED lights up with every press action.  (= button locked*) - LED lights up with every press action.
press and hold	-  (save preset) -  (fast back) -  (fast forward) - Vol+** (increase volume quickly) - Vol-** (decrease volume quickly)	 (= ok) - LED stays on as long as button is pressed/held.  (= buttons locked*) - LED stays on as long as button is pressed/held.
press and hold	-  (turn on/off)	 (= ok, battery > 40 %) - LED stays on for 2 seconds.  (= battery 10 - 40 %) - LED stays on for 2 seconds.  (= alert message, battery < 10 %, recharge necessary) - LED stays on for 2 seconds.
double press	-  (previous folder) -  (next folder)	 (= ok) - LED lights up twice on and off.  (= button locked*) - LED lights up twice on and off.
- press simultaneously	- Vol+ and Vol- (activate FullSound™ )	 (= ok) - LED lights up three times on and off.  (= button locked*) - LED lights up once on and off.
- press and hold - move	-  (return to first track) - slider (unlock buttons)	 (= ok) - LED lights up three times on and off.  (= button locked*) - LED lights up three times on and off.
press simultaneously	Vol+ and Vol- (deactivate FullSound™ )	 (= ok) - LED lights up once on and off.  (= button locked*) - LED lights up once on and off.
press	 (pause)	 (= ok) - LED flashes as long as pause is activated.  (= button locked*) - LED lights up with every press action.

connect to PC	 (charge)	▶ (= ok to disconnect, battery fully charged) - LED stays on continuously while connected. ▶ (= ok to disconnect, battery charging) - LED stays on continuously while connected and charging.
connect to PC	 (transfer files)	▶ (= ok to disconnect, transfer complete and battery fully charged) - LED stays on continuously while connected. ▶ (= transfer in progress, do not disconnect) - LED flashes while files are transferred. ▶ (= transfer complete, ok to disconnect, battery charging) - LED stays on continuously while connected and charging.

* To unlock the controls, move the slider away from lock symbol .

** Volume LED indicator extinguishes when the minimum / maximum volume level of SA018 is reached.

LED status alerts:

SA018	LED indicator
battery needs recharging	▶ (continuously 'on')
no playable files on SA018	▶ ▶ (double sequence)
error*** - software restoration required	▶ ▶ ▶ (continuous sequence)

*** SA018 requires some capacity to perform software functions. In many cases, this error can be resolved by deleting one track from the player to release more capacity for <SA018> to run.

Sound signal indicator:

Action or status	Sound indicator
turn SA018 on/off	♪ (sounds once)
battery needs recharging	♪ (once every 5 minutes)

Connect and charge

Warning

- Important: SA018 uses the USB connection with the computer to update internal software. To prevent data loss and product malfunction, do not disconnect during the update process.

SA018 has a built-in battery that can be charged as follows:

- through the combined headphone / USB jack of SA018, from a computer (with the supplied USB cable)
- through the combined headphone / USB jack of SA018, directly from the power supply (with a charger, sold separately)

Note

- While SA018 is connected to a computer or power supply, all controls and functions are inactive.
- SA018 remains in off-mode after charging process is completed.

Connect the supplied USB cable


- 1 Connect the USB plug of the supplied USB cable to a spare USB port on your computer.
- 2 Connect the special USB plug of the supplied USB cable to the combined headphone / USB jack on SA018.
- 3 Turn on your computer.
↳ SA018 charges.

Note

- For first-time use, allow SA018 to charge for 3 hours.
- While SA018 is connected to a computer, all controls and functions are inactive.
- The amber charging LED changes to green when the charging process is completed. For more information on LED status indicators, see section **Status indicators and their meanings**.

Connect the earphones

This is how to connect the supplied earphones:



Install the Philips Device Manager software

System requirements:

- Windows® (2000, XP, Vista)
- Pentium III 800 MHz processor or higher
- 128 MB RAM
- 500 MB hard disk space
- Internet connection
- Microsoft® Internet Explorer 6.0 or later
- USB port

- 1 Connect the mini USB plug of the supplied cable to SA018.
- 2 Connect the standard USB plug of the supplied cable to your computer.
↳ A pop-up window appears on the computer.
- 3 From the pop-up window, select **Install Philips Device Manager**.
- 4 Follow the on-screen instructions to complete the installation of the **Philips Device Manager**.

If the pop-up window fails to appear on the computer..

- 1 Select **My Computer** (WindowsXP® / Windows2000®) / **Computer** (WindowsVista®).
- 2 Right click on **Philips GoGear SA018**.

- 3 Select **Install Philips Device Manager**.
- 4 Follow the on-screen instructions to complete the installation of the **Philips Device Manager**.

Cannot find the file on SA018?

- 1 Ensure that your computer is connected to the Internet.
- 2 Select **My Computer** (WindowsXP® / Windows2000®) / **Computer** (WindowsVista®).
- 3 Right click on **Philips GoGear SA018**.
- 4 Select **Install Philips Device Manager from the Internet**.
- 5 Follow the on-screen instructions to complete the installation of the **Philips Device Manager** from the Internet.

Transfer music to SA018

SA018 appears as a USB mass storage device in Windows® Explorer. You can transfer and organize music files to SA018 through USB connection.

- 1 Click and highlight one or more songs to transfer between your computer and SA018.
- 2 Use drag and drop actions to complete the transfer.



Tip

- To transfer music CDs to the player: Rip (convert) the songs on your music CDs to MP3/WMA files with software such as Windows® Media Player. Copy the files into SA018 with Windows® Explorer. Free versions of these programs can be downloaded from the Internet.



Note

- SA018 requires some free memory capacity to process software updates. The removal of a music track from the memory of SA018 can fix capacity related issues.

Organize your music on SA018

SA018 can store hundreds of music tracks. To organize and facilitate locating your music, SA018 allows you to sort your music into folders.

- 1 With SA018 connected to the USB port of the computer, open Windows® Explorer.
- 2 Create folders in the mass storage of SA018.
- 3 Use drag and drop actions to sort your music into the folders.



Tip

- A double press on the ►► or ◀◀ button allows you to skip forwards or backwards through the folders on SA018, so you can quickly locate your music.

4 Enjoy

Turn SA018 on and off

- 1 To toggle between modes on and off, press and hold  for approximately 4 seconds.



Automatic shut-down

SA018 has an automatic shut-down feature that can save battery power. After 5 minutes in idle mode (no music plays, no button is pressed), SA018 switches off


- 1 Press and hold  for approximately 4 seconds to turn SA018 back on.



Listen to your music

SA018 allows you to listen to all your music in a continuous loop. SA018 has a shuffle feature, so you can listen to your music in random order.

- 1 Connect the supplied earphones.



- 2 Set the slide selector to one of the following music play options:
 -  - **Repeat all** mode (play all songs continuously)
 -  - **Shuffle*** mode (plays all songs in random order)




- 3 Press and hold  for approximately 4 seconds to turn on SA018.




- 4 Press **▶||** to start play.



- 5 Press **-VOL+** to decrease / increase the volume.



- 6 Press **◀▶** to skip to previous / next track. (Hold button to scan backward / forward within current track.)




Note

- *In **Shuffle** mode SA018 plays all the songs in random order before it repeats a song.


Listen to FM radio

SA018 has a built-in FM radio tuner; Here's how to listen to FM radio:

- 1 Connect the supplied earphones.



- 2 Set the slide selector to position **FM**.




- 3 Press and hold **⏻** for approximately 4 seconds to turn on SA018.




↳ Radio starts automatically.

- 4 Press **-VOL+** to increase / decrease the volume.



- 5 Press **◀▶** to decrease / increase the radio frequency. (Hold button to scan radio frequencies down / up.)



You can store up to 5 radio stations (frequencies) to a preset:

- 1 Press and hold **▶▶** to save the frequency to preset.
 - ↳ Once all 5 presets are taken, SA018 overwrites the existing presets with newly saved frequencies, beginning with preset that is least used.



Note

- The cable of the earphones serves as a radio antenna. Ensure you connect the earphones properly for an optimal reception.

5 Use SA018 to carry files

SA018 allows you to carry files in **Windows Explorer**.


- 1 With SA018 connected to the USB port of the computer, open **Windows Explorer**.
- 2 Create folders in SA018.
- 3 Use drag and drop actions to sort your files into the folders.

6 Troubleshooting

How do I reset my player?

- Insert a pen tip or other object into the reset hole located at the bottom of SA018. Hold until the player shuts down.
- If the reset option is unsuccessful, follow the steps how to recover SA018 with the **Philips Device Manager**:

- 1 On your computer, select **Start > Programs > Philips Digital Audio Player > SA018 Device Manager > Philips Device Manager** to launch the **Philips Device Manager**.
- 2 Press and hold the volume button  while you connect SA018 to your computer.



- 3 Keep holding the key until the **Philips Device Manager** acknowledges SA018 and enters the recovery mode.
- 4 On the computer, click the **Repair** button and follow the instructions of the **Philips Device Manager** to complete the recovery process.
- 5 When the recovery is completed, disconnect SA018 from your computer.
- 6 Restart SA018.

7 Technical data

Power

Li-ion polymer internal rechargeable battery
Play time (music): up to 12 hours

System requirements

Windows® 2000, XP, Vista
Pentium III 800 MHz processor or higher
128 MB RAM
500 MB hard disk space
Internet connection
Microsoft® Internet Explorer 6.0 or later
Sound card
USB port

Sound

Frequency Response: 20 Hz - 18 kHz
Signal to noise ratio: > 84 dB
Channel separation: 45 dB
Output power: 2 x 2.4 mW
THD: 0.05% at 1 kHz
Sound enhancement: **FullSound™**

Storage media

Built-in memory capacity:
SA018102 2GB NAND Flash
SA018104 4GB NAND Flash
Mass storage class compliant

Software

Philips Device Manager: to restore and upgrade

Connectivity

Headphone 3.5 mm

Audio playback

Compression format: MP3, WMA
MP3 bit rates: 8-320 kps and VBR
WMA bit rates: 5 - 320 kbps
MP3 sample rates: 8, 11.025, 16, 22.050, 24, 32, 44.1, 48 kHz
WMA sample rates: 8, 11.025, 16, 22.050, 24, 32, 44.1, 48 kHz

Tuner / Reception / Transmission

Station presets: 5
Tuner band: FM

Music transfer

Drag and drop in Windows® Explorer

Supported music file formats

SA018 supports the following music formats:

- MP3
- unprotected WMA

8 Glossary

D

Decibel (dB)

A unit of measure used to express relative difference in power or intensity of sound.

F

FullSound

FullSound™ is an innovative technology designed by Philips. FullSound™ faithfully restores sonic details to compressed music, enhancing it to provide a full sound experience without any distortion.

L

LCD (Liquid Crystal Display)

Probably the most common way to show visual information on non-computer electronic equipment.

S

Shuffle

A feature that plays audio files (tracks) in random order.

Streaming

A technique for transferring data such that it can be processed as a steady and continuous stream. Streaming technologies are often used on the Internet because many users do not have fast enough access to download large multimedia files quickly, so the client browser or plug-in can start displaying the data before the entire file has been transmitted.

V

Volume

Volume is the most common word used to specify the control of relative loudness of

sounds. It also pertains to the function on many electronic devices that is used to control the loudness.

W

WMA (Windows Media Audio)

An audio format owned by Microsoft, is a part of Microsoft Windows Media technology. Includes Microsoft Digital Rights Management tools, Windows Media Video encoding technology, and Windows Media Audio encoding technology.

