

Always there to help you

Register your product and get support at www.philips.com/welcome



EN	User manual	NL	Gebruiksaanwijzing	
DE	Benutzerhandbuch		دليل المستخدم	AR
FR	Mode d'emploi		راهنمای کاربرد	FA
IT	Manuale utente			

Register your product and get support at www.philips.com/welcome

PHILIPS

Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC. Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

2 Before first use

Before you use the appliance and accessories for the first time, thoroughly clean the parts that come into contact with food.

To explore more helpful tips and basic recipes online, you can:

- Go to www.philips.com.
- Click the search button  on the homepage.
- Type the product number "HR7759" in the search box.
- Find or download the information you need from the searching result.

3 Food processor

General Assembly

Before you use or assemble any of the accessories, make sure that you assemble according to Fig. 2 to 7.

- Align the indicator on the bowl edge to the unlocking symbol on the motor unit and attach the bowl to the motor unit.
- Turn the bowl clockwise until you hear a click to fix it onto the motor unit.
- Assemble the accessory or the accessory equipped with the shaft to the bowl.
- Put the ingredients in the bowl.
- Put the lid on the bowl, and turn the lid clockwise until you hear a click to fix it. Then put the pusher into the feeding tube.
 - For the discs, put the ingredients into the feeding tube with the pusher.
- Connect the power plug to the power supply.
- Check the advised ingredient quantity and setting in Table 1. Turn the knob to the desired speed setting.
- After use, turn the knob to 0, and then unplug the appliance.

Blade unit

Before you start, make sure that you assemble according to Fig. 2. You can use the blade unit to chop, mix, or puree ingredients. To remove the food that sticks to the blade or bowl wall, stop processing and switch off the appliance first, and then use a spatula.

Note

- Always put the blade unit in the bowl before you start to add the ingredients.
- Do not use the blade unit to chop hard ingredients like coffee beans, turmeric, nutmeg, and ice cubes, as this may cause the blade to get hurt.
- Do not let the appliance run too long when you chop (hard) cheese or chocolate. Otherwise these ingredients become too hot, start to melt, and turn lumpy.

Danger

- Do not immerse the motor unit in water nor rinse it under the tap.

Warning

- Never use your fingers or an object to push ingredients into the feeding tube while the appliance is running. Only use the pusher.
- Before you connect the appliance to the power, make sure that the voltage indicated on the bottom of the appliance corresponds to the local power voltage.
- Never connect this appliance to a timer switch, to avoid a hazardous situation.
- Do not use the appliance if the power cord, the plug, protecting cover, or any other parts are damaged or has visible cracks.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons to avoid a hazard.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- For their safety, do not allow children to play with the appliance.
- Never let the appliance run unattended.
- If food sticks to the wall of the blender jar or bowl, switch off the appliance and unplug it. Then use a spatula to remove the food from the wall.
- Be careful when you handle or clean the discs, the blade unit of the food processor, and the blade unit of the blender. The cutting edges are very sharp.
- Do not touch the blades, especially when the appliance is plugged in. The blades are very sharp.
- If the blades get stuck, unplug the appliance before you remove the ingredients that block the blades.
- Be careful if hot liquid is poured into the food processor or blender as it can be ejected out of the appliance due to a sudden steaming.
- This appliance is intended for household only.

Caution

- Never switch off the appliance by turning the blender jar, the bowl, or their lids. Always switch off the appliance by turning the speed selector to 0.
- Unplug the appliance immediately after use.
- Always wait until the moving parts stop running, then switch off and unplug the appliance before

opening the lid and reaching into any of the parts that move in use.

- Before you remove, clean or change the accessories, switch off and unplug the appliance.
- Thoroughly clean the parts that come into contact with food before you use the appliance for the first time.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not exceed the maximum level indication on the bowl or the jar. Follow the quantities, processing time and speed as indicated in the user manual.
- Let hot ingredients cool down (< 80°C) before processing them.
- Always let the appliance cool down to room temperature after each batch that you process.
- Certain ingredients may cause discolorations on the surface of the parts. This does not have a negative effect on the parts. The discolorations usually disappear after some time.
- Noise level = 78 dB (A)

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC. Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

2 Before first use

Before you use the appliance and accessories for the first time, thoroughly clean the parts that come into contact with food.

To explore more helpful tips and basic recipes online, you can:

- Go to www.philips.com.
- Click the search button  on the homepage.
- Type the product number "HR7759" in the search box.
- Find or download the information you need from the searching result.

3 Food processor

General Assembly

Before you use or assemble any of the accessories, make sure that you assemble according to Fig. 2 to 7.

- Align the indicator on the bowl edge to the unlocking symbol on the motor unit and attach the bowl to the motor unit.
- Turn the bowl clockwise until you hear a click to fix it onto the motor unit.
- Assemble the accessory or the accessory equipped with the shaft to the bowl.
- Put the ingredients in the bowl.
- Put the lid on the bowl, and turn the lid clockwise until you hear a click to fix it. Then put the pusher into the feeding tube.
 - For the discs, put the ingredients into the feeding tube with the pusher.
- Connect the power plug to the power supply.
- Check the advised ingredient quantity and setting in Table 1. Turn the knob to the desired speed setting.
- After use, turn the knob to 0, and then unplug the appliance.

Blade unit

Before you start, make sure that you assemble according to Fig. 2. You can use the blade unit to chop, mix, or puree ingredients. To remove the food that sticks to the blade or bowl wall, stop processing and switch off the appliance first, and then use a spatula.

Note


- Always put the blade unit in the bowl before you start to add the ingredients.
- Do not use the blade unit to chop hard ingredients like coffee beans, turmeric, nutmeg, and ice cubes, as this may cause the blade to get hurt.
- Do not let the appliance run too long when you chop (hard) cheese or chocolate. Otherwise these ingredients become too hot, start to melt, and turn lumpy.

Kneading accessory

Before you start, make sure that you assemble according to Fig. 3. You can use the kneading accessory to knead yeast dough for bread and pizzas. You need to adjust the amount of liquid to form the dough according to the humidity and temperature condition.

Discs and Inserts

Before you start, make sure that you pick your desired disc from following and assemble according to Fig. 4 and Fig. 5.

Disc/insert	Name	Purpose
	Emulsifying disc	To prepare food like whipped cream through whipping or whisking
	Insert for fine slicing	To cut ingredients into thin flat pieces
	Insert for coarse slicing	To cut ingredients into thick flat pieces
	Insert for fine shredding	To cut or tear cheese or raw vegetables into fine thread
	Insert for coarse shredding	To cut or tear cheese or raw vegetables into thicker thread
	Insert for granulating	To form or crystallize ingredients into grains or granules
	Disc for slicing / shredding (fine)	To cut ingredients into thin flat pieces / fine threads
	Disc for slicing / shredding (coarse)	To cut ingredients into thick flat pieces / thicker threads
	Disc for French fry	To cut ingredients into thicker strips
	Disc for granulating	To form or crystallize ingredients into grains or granules
	Disc for julienne	To cut ingredients into fine strips

To assemble the disc inserts, follow the steps below:

- Place the opening of the insert over the shaft of the insert holder.
- Push the opening of the insert over the projection on the shaft.
- Press the insert onto the insert holder until it locks in position with a click.

! Caution

- Be careful when you handle the slicing blade of disc. It has a very sharp cutting edge.
- Never use the disc to process hard ingredients like ice cubes.
- Do not exert too much pressure on the pusher when you press ingredients into the feed tube.

Note

- Put the ingredients into the feeding tube with the pusher. Fill the feeding tube evenly for the best result. When you have to process a large amount of ingredients, process small batches and empty the bowl between batches.

Mini chopper

Before you start, make sure you assemble according to Fig. 6.

You can use the mini chopper to chop coffee beans, peppercorns, nuts, herbs, dried fruits etc.

Note

- You can order a mini chopper jar and a blade unit (under service code number 9965 100 57198/9965 100 52997) from your Philips dealer or a Philips service center as extra accessories.
- Follow the recommendation on Table 1. Do not exceed the maximum level indicated on the mini chopper.

*** Tip**

- For best results when processing beef, please use refrigerated beef cubes. Use max of 100g beef cubes at speed P for 5 sec.
- How to remove the ingredients that stick to the side of the mini chopper? 1. Switch off the appliance, and then unplug it. 2. Remove the beaker from the blade unit. 3. Remove the ingredients from the blade or from the side of the beaker with a spoon.

4 Blender

Before you start, make sure you assemble according to Fig. 7.

The blender is intended for:

- Blending fluids, like dairy products, sauces, fruit juices, soups, mixed drinks, and shakes.
- Mixing soft ingredients, like pancake batter.
- Pureeing cooked ingredients, like baby food.

Note

- Never open the lid to put your hand or any object in the jar while the blender is running.
- Always assemble the sealing ring onto the blade unit before you attach the blade unit to the blender jar.
- To add liquid ingredients during processing, pour them into the blender jar through the feeding hole.
- Pre-cut ingredients into small pieces before you process them.
- If you want to prepare a large quantity, process small batches of ingredients instead of a large quantity at once.
- To avoid spillage: When you process a liquid tends to foam (for example, milk), do not put more than 1 liter of liquid in the blender jar.
- Put the ingredients in the blender jar within the maximum level indication.

5 Cleaning and storage

! Caution

- Make sure that the cutting edges of the blades and discs do not come into contact with hard objects. This may cause the blades to be dull.
- The cutting edges are sharp. Be careful when you clean the blade unit of the food processor; the blade unit of the blender and the discs.

- Clean the motor unit with a moist cloth.
- Clean the other parts in hot water (< 60°C) with some washing-up liquid or in a dishwasher.
- Store the product in a dry place.

6 Guarantee and service

If you have a problem, need service, or need information, see www.philips.com/support or contact the Philips Consumer Care Center in your country. The phone number is in the worldwide guarantee leaflet. If there is no Consumer Care Center in your country, go to your local Philips dealer.

Deutsch

Herzlichen Glückwunsch zu Ihrem Kauf und willkommen bei Philips! Um das Kundendienstangebot von Philips vollständig nutzen zu können, registrieren Sie Ihr Produkt unter www.philips.com/welcome.

Lesen Sie diese Bedienungsanleitung vor dem Gebrauch des Geräts aufmerksam durch und bewahren Sie sie für eine spätere Verwendung auf.

Achtung!

- Tauchen Sie die Motoreinheit niemals in Wasser. Spülen Sie sie auch nicht unter fließendem Wasser ab.

Warnung

- Verwenden Sie nie Ihre Finger oder einen Gegenstand, um Zutaten in die Einfüllöffnung zu schieben, während das Gerät läuft. Verwenden Sie ausschließlich den Stopfer.
- Bevor Sie das Gerät an eine Steckdose anschließen, überprüfen Sie, ob die auf der Unterseite des Geräts angegebene Spannung mit der Netzspannung vor Ort übereinstimmt.
- Um Gefährdungen zu vermeiden, sollten Sie das Gerät nie an einen Zeitschalter anschließen.
- Verwenden Sie das Gerät nicht, wenn das Netzkabel, der Stecker, die Schutzabdeckung oder andere Teile beschädigt sind oder sichtbare Risse aufweisen.
- Ist das Netzkabel defekt, darf es nur von einem Philips Service-Center, einer von Philips autorisierten Werkstatt oder einer ähnlich qualifizierten Person durch ein Original-Ersatzkabel ausgetauscht werden, um Gefährdungen zu vermeiden.
- Dieses Gerät sollte nicht von Kindern verwendet werden. Halten Sie das Gerät und das Netzkabel außerhalb der Reichweite von Kindern.
- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an Erfahrung und Kenntnis verwendet werden, wenn sie bei der Verwendung beaufsichtigt wurden oder Anweisung zum sicheren Gebrauch des Geräts erhalten und die Gefahren verstanden haben.
- Erlauben Sie Kindern zu ihrem Schutz nicht, mit dem Gerät zu spielen.
- Lassen Sie das eingeschaltete Gerät niemals unbeaufsichtigt.
- Wenn Zutaten innen am Mixbecher haften bleiben, schalten Sie das Gerät aus, und ziehen Sie den Stecker aus der Steckdose. Lösen Sie die Zutaten dann mithilfe eines Teigschabers von der Behcerwand.
- Seien Sie äußerst vorsichtig, wenn Sie die Scheiben, die Messereinheit der Küchenmaschine und die Messereinheit des Mixers verwenden bzw. reinigen. Die Klingen sind sehr scharf.
- Berühren Sie die Messer nicht, besonders wenn das Gerät an das Stromnetz angeschlossen ist. Die Messer sind sehr scharf.
- Wenn die Messer blockiert sind, ziehen Sie stets den Netzstecker aus der Steckdose, bevor Sie die blockierenden Zutaten entfernen.
- Seien Sie vorsichtig, wenn heiße Flüssigkeiten in die Küchenmaschine oder den Mixer gegossen werden, da diese durch unvermittelt auftretenden Dampf herausspritzen können.
- Dieses Gerät ist nur für den Gebrauch im Haushalt bestimmt.

- Schalten Sie das Gerät nie durch Drehen des Mixbechers, der Schüssel oder deren Deckel aus. Stellen Sie zum Ausschalten des Geräts immer den Geschwindigkeitsregler auf 0.
- Ziehen Sie nach Gebrauch sofort den Netzstecker aus der Steckdose.
- Erst, wenn alle beweglichen Teile zum Stillstand gekommen sind, das Gerät ausgeschaltet und der Netzstecker gezogen wurde, sollten Sie den Deckel abnehmen und Teile anfassen, die sich bei Gebrauch bewegen.
- Schalten Sie vor dem Entfernen, Reinigen oder Wechseln von Zubehör das Gerät aus, und ziehen Sie den Netzstecker aus der Steckdose.
- Reinigen Sie vor dem ersten Gebrauch des Geräts alle Teile, die mit Lebensmitteln in Kontakt kommen.
- Verwenden Sie niemals Zubehör oder Teile, die von Dritten/stellern stammen bzw. nicht von Philips

empfohlen werden. Wenn Sie diese(s) Zubehör oder Teile verwenden, erlischt Ihre Garantie.

- Füllen Sie die Schüssel bzw. den Mixbecher nicht über die jeweils oberste Markierung hinaus. Befolgen Sie die Mengenangaben, Verarbeitungszeiten und Geschwindigkeitsstufen, die in der Bedienungsanleitung angegeben sind.
- Lassen Sie heiße Zutaten abkühlen (< 80 °C), bevor Sie sie verarbeiten.
- Lassen Sie das Gerät immer auf Raumtemperatur abkühlen, bevor Sie die nächste Portion verarbeiten.
- Bestimmte Zutaten können die Oberfläche der Teile verfärben. Dies wirkt sich nicht negativ auf die Teile aus. Die Verfärbungen verschwinden gewöhnlich nach einer gewissen Zeit.
- Geräuschpegel = 78 dB (A)

Elektromagnetische Felder

Dieses Philips Gerät erfüllt sämtliche Normen und Regelungen bezüglich der Exposition in elektromagnetischen Feldern (EMF). Nach aktuellen wissenschaftlichen Erkenntnissen ist das Gerät sicher im Gebrauch, sofern es ordnungsgemäß und entsprechend den Anweisungen in dieser Bedienungsanleitung gehandhabt wird.

Recycling

Ihr Gerät wurde unter Verwendung hochwertiger Materialien und Komponenten entwickelt und hergestellt, die recycelt und wiederverwendet werden können. Befindet sich das Symbol einer durchgestrichenen Abfalltonne auf Rückem auf dem Gerät, bedeutet dies, dass für dieses Gerät die Europäische Richtlinie 2002/96/EG gilt. Entsorgen Sie Ihr Produkt niemals zusammen mit dem normalen Hausmüll. Bitte informieren Sie sich über die örtlichen Bestimmungen zur getrennten Entsorgung von elektrischen und elektronischen Produkten. Die korrekte Entsorgung des nicht mehr benötigten Produkts hilft, negative Auswirkungen auf Umwelt und Gesundheit zu vermeiden.

2 Vor dem ersten Gebrauch

Bevor Sie das Gerät und das Zubehör zum ersten Mal verwenden, reinigen Sie die Teile gründlich, die mit Nahrungsmitteln in Kontakt kommen.

Weitere hilfreiche Tipps und einfache Rezepte finden Sie online:

- Besuchen Sie www.philips.com.
- Klicken Sie auf die Schaltfläche zum Suchen  auf der Website.
- Geben Sie die Produktnummer «HR7759» in das Suchfeld ein.
- Suchen Sie in den Suchergebnissen nach den benötigten Informationen, oder laden Sie diese herunter.

3 Küchenmaschine

Allgemeine Montage

Vor dem Gebrauch oder der Montage der Zubehörtteile, vergewissern Sie sich, dass Sie die Montage gemäß Abb. 2 bis 7 vornehmen.

- Richten Sie die Anzeige am Rand der Schüssel am Entsperrsymbol auf der Motoreinheit aus und setzen Sie die Schüssel auf die Motoreinheit.
- Drehen Sie die Schüssel im Uhrzeigersinn, bis sie hörbar auf der Motoreinheit einrastet.
- Setzen Sie das Zubehör oder das Zubehör mit dem Schaft in die Schüssel ein.
- Geben Sie die Zutaten in die Schüssel.
- Setzen Sie den Deckel auf die Schüssel, und drehen Sie den Deckel im Uhrzeigersinn, bis er hörbar einrastet. Setzen Sie dann den Stopfer in die Einfüllöffnung.
 - Füllen Sie bei den Scheiben die Zutaten mit dem Stopfer in die Einfüllöffnung.
- Schließen Sie den Stecker an die Steckdose an.
- Entnehmen Sie die empfohlene Mengenangabe und Einstellung der Tabelle 1. Drehen Sie den Schalter auf die gewünschte Geschwindigkeitsstufe.
- Drehen Sie den Regler nach der Verwendung auf 0, und ziehen Sie den Netzstecker des Geräts aus der Steckdose.

Messereinheit

Bevor Sie beginnen, vergewissern Sie sich, dass Sie die Teile gemäß der Abbildung montieren. 2. Mit der Messereinheit können Sie Zutaten hacken, mixen oder pürieren. Um die Speisen, die am Messer oder der Innenseite der Schüssel haften bleiben zu entfernen, halten Sie das Gerät zunächst an, schalten Sie es aus, und setzen Sie dann einen Teigschaber ein.

Anmerkung

- Setzen Sie stets die Messereinheit in die Schüssel, bevor Sie Zutaten einfüllen.
- Zerkleinern Sie mit der Messereinheit keine harten Zutaten wie Kaffeebohnen, Kurkuma, Muskatnüsse oder Eiwürfel, da die Messer sonst stumpf werden.
- Lassen Sie das Gerät nicht an Wälle oder wenn Sie Hart Wälle oder Schokolade zerkleinern. Ansonsten werden diese Zutaten zu heiß, schmelzen und werden klumpig.

Knetthaken

Bevor Sie beginnen, vergewissern Sie sich, dass Sie die Teile gemäß der Abbildung montieren. 3. Mit dem Knetthaken können Sie Hefeteig für Brot und Pizzen kneten. Sie müssen die Flüssigkeitsmenge einstellen, um den Teig gemäß der Luftfeuchtigkeits- und Temperaturbedingungen zu formen.

Scheiben und Einsätze

Bevor Sie beginnen, vergewissern Sie sich, dass Sie Ihre gewünschte Scheibe aus den folgenden auswählen und Sie gemäß Abb. 4 und Abb. 5.

Scheibe/ Einsatz	Name	Zweck
	Emulgierscheibe	Zubereitung von Speisen wie Schlagahne durch Schlagen
	Einsatz zum feinen Schneiden	Schneiden von Zutaten in kleine, flache Stücke
	Einsatz zum groben Schneiden	Schneiden von Zutaten in größere, flache Stücke
	Einsatz zum feinen Raspeln	Schneiden von Käse oder rohem Gemüse in feine Raspel
	Einsatz zum groben Raspeln	Schneiden von Käse oder rohem Gemüse in grobe Raspel
	Einsatz zum Reiben	Reiben von Zutaten in feine Stückchen
	Scheibe zum Schneiden/ Raspeln (fein)	Schneiden von Zutaten in kleine, flache Stücke/ feine Raspel
	Scheibe zum Schneiden/ Raspeln (grob)	Schneiden von Zutaten in größere, flache Stücke/grobe Raspel
	Pommes-Frites-Scheibe	Schneiden von Zutaten in dicke Streifen
	Scheibe zum Reiben	Reiben von Zutaten in feine Stückchen
	Julienne-Scheibe	Schneiden von Zutaten in feine Streifen

Gehen Sie zum Zusammensetzen der Scheibeneinheit wie folgt vor:

- Platzieren Sie die Öffnung des Einsatzes über dem Schaft des Einsatzhalters.
- Schieben Sie die Öffnung des Einsatzes über die Ausbuchtung am Schaft.
- Drücken Sie den Einsatz in den Einsatzhalter, bis er hörbar einrastet.

! Vorsicht

- Gehen Sie vorsichtig mit der Messereinheit der Scheibe um. Sie hat eine sehr scharfe Klinge.
- Verarbeiten Sie mit den Scheiben keine harten Zutaten wie Eiwürfel.
- Üben Sie nicht zu viel Druck auf den Stopfer aus, wenn Sie Zutaten in die Einfüllöffnung füllen.

Anmerkung

- Drücken Sie die Zutaten mit dem Stopfer in die Einfüllöffnung. Die besten Ergebnisse erhalten Sie, wenn Sie die Einfüllöffnung gleichmäßig füllen. Verarbeiten Sie größere Mengen nicht auf einmal, sondern in mehreren kleinen Portionen, nacheinander. Leeren Sie zwischendurch die Schüssel.

Mini Chopper

Bevor Sie beginnen, vergewissern Sie sich, dass Sie die Teile gemäß der Abbildung montieren. 6. Sie können den Mini-Zerkleinerer zum Zerkleinern von Kaffeebohnen, Pfefferkörnern, Nüssen, Kräutern, getrockneten Früchten usw. verwenden.

Anmerkung

- Einem Mixbecher für den Mini-Zerkleinerer und eine Messereinheit können Sie (unter Telefonnummer 9965 100 57198/9965 100 52997) bei Ihrem Philips Händler oder einem Philips Service-Center als zusätzliches Zubehör bestellen.
- Befolgen Sie die Empfehlungen in Tabelle 1. Überschreiten Sie nicht die angegebene maximale Füllmenge des Mini-Zerkleinerers.

*** Tipp**

- Für die besten Ergebnisse bei der Verarbeitung von Rindfleisch, verwenden Sie bitte gekühlte Rindfleischwürfel. Verwenden Sie für 5 Sekunden bei Geschwindigkeit P maximal 100 g Rindfleischwürfel.
- Wie entferne ich Zutaten, die an der Wand des Mini-Zerkleinerers haften? 1. Schalten Sie das Gerät aus, und ziehen Sie den Netzstecker aus der Steckdose. 2. Nehmen Sie den Becher von der Messereinheit ab. 3. Verwenden Sie einen Löffel, um die Zutaten vom Messer und von der Innwand des Bechers zu entfernen.

4 Mixer

Bevor Sie beginnen, vergewissern Sie sich, dass Sie die Teile gemäß der Abbildung montieren. 7. Der Standmixer ist geeignet zum:

- Mixen von Flüssigkeiten, z.B. Milchprodukte, Saften, Obstsaften, Suppen, Mixgetränke, Milchshakes
- Mischen weicher Zutaten, z. B. Pfannkuchenteig
- Pürieren gekochter Zutaten, z. B. Babyahrung

Anmerkung

- Öffnen Sie nie den Deckel, um Ihre Hand oder einen Gegenstand in den Behälter zu führen, wenn der Motor läuft.
- Setzen Sie immer den Dichtungsring auf die Messereinheit, bevor Sie diese in den Mixbecher einsetzen.
- Zum Einfüllen von Flüssigen Zutaten bei laufendem Gerät geben Sie sie durch die Einfüllöffnung in den Behälter.
- Schneiden Sie Zutaten in kleinere Stücke, bevor Sie sie verarbeiten.
- Verarbeiten Sie größere Mengen nicht auf einmal, sondern in mehreren kleinen Portionen nacheinander.
- Um Auslaufen zu vermeiden: Wenn Sie leicht schäumende Flüssigkeiten (z. B. Milch) verarbeiten, sollten Sie höchstens 1 Liter in den Mixbecher füllen.
- Geben Sie die Zutaten bis zur maximalen Füllmenge in den Mixbecher.

5 Reinigung und Aufbewahrung

! Vorsicht

- Achten Sie darauf, dass die Klingen der Messer und der Scheiben nicht mit harten Gegenständen in Berührung kommen. Sie könnten stumpf werden.
- Die Klingen sind sehr scharf. Seien Sie vorsichtig, wenn Sie die Messereinheit der Küchenmaschine, die Messereinheit des Standmixers und die Scheiben reinigen.

- Reinigen Sie

