

PHILIPS

AC4030



EN User manual 3

ZH-TW 使用手冊 29



Contents

1	Important	4
	Safety	4
2	Your air purifier	8
	Overview	9
3	Getting started	11
	Install the anti-virus cartridge	11
	Connect	14
	Switch on and change the fan speed	15
4	Cleaning your air purifier	18
5	Replacing the anti-virus cartridge	19
6	Replacing the AC filter	22
7	Troubleshooting	24
8	Guarantee and service	26
	Order parts or accessories	26
9	Notices	27
	Electromagnetic fields (EMF)	27
	Recycling	28

1 Important

Safety

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let water or any other liquid or flammable detergent enter the appliance to avoid electric shock and/or a fire hazard.
- Do not clean the appliance with water, any other liquid, or a (flammable) detergent to avoid electric shock and or a fire hazard.
- Do not operate switches while driving.
- Do not install the appliance where it could hamper visibility to the front or driving operations, or in place where it could be dangerous to passengers.

Warning

- Check if the voltage indicated on the bottom or at the rear of the appliance corresponds to an automobile outlet for 12V or to the local power voltage before you connect the appliance.
- This appliance is designed for use in vehicles with 12V batteries. Do not use it in large trucks, buses, or other vehicles with 24V batteries.
- Do not pull on the power cord when unplugging the automobile adapter or the connection plug.
- Only use the power supply unit provided with the appliance.

- 
- 
- 
- When transporting, be careful not to drop the appliance or subject it to shocks. Continued usage as such could lead to fire or electric shock.
 - Do not use the appliance if the automobile adapter, plug, the power cord, or the appliance itself is damaged.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experiences and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
 - Do not block the air inlet and outlet, e.g. by placing items on the air outlet or air inlet.
 - Do not soak the product in water.
 - Disconnect the power and remove the automobile adapter from the cigar socket before replacing the anti-virus cartridge*, replacing the AC filter, or cleaning the appliance.
 - Disconnect the power and remove the automobile adapter from the cigar socket when the appliance is not in use for an extended period of time.
 - If the cigar socket and ashtray are in one integrated unit, use the product after the cigar light is gone.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of deodorizer.

- If the power socket used to power the appliance has poor connections, the plug of the appliance becomes hot. Make sure that you plug the appliance into a properly connected power socket.
- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- For use in car, it is recommended to place the product in the cup holder of the car.
- Do not place the appliance in commercially available cup holders, air vent car holder, or any kind of unstable car mounts.
- If the appliance risks falling out of the cup holder, especially when driving on rough roads, over bumps, etc., either slow down or remove the appliance from the cup holder beforehand.
- Do not place anything around the appliance nor sit on it.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure the AC filter and the anti-virus cartridge are properly installed before you switch on the appliance.
- Only use the original Philips AC filter and anti-virus cartridge specially intended for this appliance. Do not use any other.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Do not insert your fingers or objects into the air outlet.

- 
- 
- 
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
 - Do not use the appliance near gas appliance, heating devices, or fireplaces.
 - Always unplug the appliance after use and before you clean it.
 - Do not use the appliance in a room or in a vehicle with major temperature changes, as this may cause condensation inside the appliance.
 - For residential use, place the appliance at least 2m away from electrical appliance that use airborne radio waves such as TVs, radios, and radio-controlled clocks to prevent interference.
 - The appliance is only intended for household and vehicle use under normal operating conditions.
 - Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
 - This appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
 - The anti-virus cartridge may emit a distinct scent. If the scent discomforts you, please increase ventilation, e.g. by opening the window or stop using the appliance.

* Tested for MS2 virus species removal at Intertek Institute, USA (tested in 11 m3 chamber).


2 Your air purifier

Congratulations on your purchase, and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome. Read this user manual carefully before you install and use the unit. Save it for future reference.

Overview

Check and identify the product parts.



- 
- 
- 
- ① Fan speed button
 - ② Light button
 - ③ Air inlet
 - ④ Bottom cover
 - ⑤ Air outlet
 - ⑥ Power-in socket
 - ⑦ AC filter (Activated carbon filter)
 - ⑧ Anti-virus cartridge
 - ⑨ Brush
 - ⑩ AC/ DC adapter
 - ⑪ Automobile adapter

3 Getting started

Install the anti-virus cartridge




The appliance comes with all accessories, but you have to remove the packaging of the anti-virus cartridge and insert it in the appliance before you can use it. Remove the plastic and the 2 small stickers, and place it into the appliance as described below.



Note






- Always unplug the purifier before you install the anti-virus cartridge. (Figure 1)
- Insert the cartridge in the correct position.

- 1 Turn the bottom cover clockwise to open. (Figure 2)
- 2 Detach the front panel cover. (Figure 3)



- 3 Remove 2 small stickers of the new cartridge before placing it in. (Figure 4-6)
- 4 To reattach the front panel cover, insert the top hooks into the top of the appliance first ①. Then, push the panel against the body of the appliance ②. (Figure 7)

- 5 Place the bottom cover, and turn it anti-clockwise to close. (Figure 8)



Connect



For automobile



Caution



- Do not block the air outlet when installing the product.
- If you place the product in front of an air conditioner, it might be heated when the car heater is on. Be careful not to get injured.

- 1 Connect the automobile adapter to the power-in socket. (Figure 1)
- 2 Connect the cigar plug to the cigar socket. (Figure 2)



For home or office

- 1 Connect the AC/DC adapter into the power-in socket. (Figure 1)
- 2 Connect the power plug to the power socket. (Figure 2)



Switch on and change the fan speed



Caution

- When you turn off the engine or take off the key of your car, disconnect the cigar plug to prevent the car battery from discharging.




Note

- If you turn off the car while using the air purifier, it will operate in level 1 fan speed when you restart your car.
- There are 2 levels of fan speed.
- For energy saving, the air purifier switches off automatically every 8 hours. You need to press the fan speed button manually to switch on the air purifier.

- 1 Press the fan speed button to switch on the air purifier.
 - ↳ The air purifier operates in level 1 fan speed. (Figure 1)
 - ↳ The light indicator illuminates automatically. To turn off the light indicator, you can press the light button to turn off. (Figure 4-5)
- 2 Press the fan speed button again to change to higher fan speed. (Figure 2)

- 3 Press the fan speed button the third time to switch off the air purifier. (Figure 3)



4 Cleaning your air purifier




Note

- Always unplug the purifier before you clean it.
- Never immerse the purifier in water or any other liquid.
- Never use abrasive aggressive or flammable cleaning agents, such as bleach or alcohol to clean any parts of the purifier.

Regularly clean the inside and outside of the purifier body to prevent dust from collecting.

- 1 Wipe away dust with a soft dry cloth from the body of the purifier.
- 2 Clean the air inlet and the air outlet with the cleaning brush.
 - The cleaning brush can be mounted on the side of air purifier's interior after use.






5 Replacing the anti-virus cartridge



Note






- Always unplug the purifier before you replace the anti-virus cartridge. (Figure 1)
- Replace the anti-virus cartridge every 3 months.
- Insert the anti-virus cartridge in the correct position.

- 1 Turn the bottom cover clockwise to open. (Figure 2)
- 2 Remove the front panel cover. (Figure 3)



- 3 Remove the plastic and 2 small stickers of the new cartridge before placing it in. (Figure 4-6)
- 4 To reattach the front panel cover, insert the top hooks into the top of the appliance first ①. Then, push the panel against the body of the appliance ②. (Figure 7)

- 5 Place the bottom cover back, and turn it anti-clockwise to close. (Figure 8)






6 Replacing the AC filter






Note

- Always unplug the purifier before you replace the AC filter. (Figure 1)
- Replace the AC filter every 6 months.
- Insert the filter in the correct position.

- 1 Turn the bottom cover clockwise to open. (Figure 2)
- 2 Remove the AC filter. (Figure 3)



- 3 Remove the packaging material of the filter, then insert the new filter. (Figure 4-5)
- 4 Place the bottom cover back, and turn it anti-clockwise to close. (Figure 8)



7 Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
No air comes out from the air outlet.	• The purifier is not connected to the power supply. Connect the purifier into the power supply and switch on. • Check if the voltage indicated on the bottom or at the rear of the air purifier corresponds to an automobile outlet for 12V or to the local power voltage before you connect the air purifier.
The airflow that comes out of the air outlet is significantly weaker than before.	• Check the filters replacement cycles. Replace if necessary.



Problem	Possible solution
An odor comes out of the air outlets.	• Check the filters replacement cycles. Replace if necessary. • The anti-virus cartridge emits a distinct scent. This scent comes from the natural ingredients that remove the viruses* in the indoor air around you. The intensity of the perceived smell decreases if you position the device at a larger distance and/or out of direct sunlight at a cooler position.



* Tested for MS2 virus species removal at Intertek Institute, USA (tested in 11m³ chamber).





8 Guarantee and service

If you need information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Center in your country (you will find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Center in your country, go to your local Philips dealer.

Order parts or accessories



If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you will find its phone number in the worldwide guarantee leaflet).



9 Notices

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Compliance with EMF

Koninklijke Philips N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.



Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

目錄

1	重要事項	30
	安全	30
2	您的空氣清淨機	34
	概覽	35
3	快速入門	37
	安裝抗病毒蕊盒	37
	連接	40
	開啟電源並變更風速	42
4	清潔空氣清淨機	44
5	更換抗病毒蕊盒	45
6	更換活性碳濾網	48
7	疑難排解	50
8	保固與服務	51
	訂購零件或配件	51
9	聲明	52
	電磁場 (EMF)	52
	回收	53



1 重要事項

安全

在使用本產品前，請先仔細閱讀本使用手冊，並保留說明以供日後參考。

危險

- 請勿讓水或其他液體，或是易燃清潔劑進入產品內，以避免電擊和 / 或火災。
- 請勿用水、其他液體，或是 (易燃) 清潔劑清潔產品，以避免電擊和 / 或火災。
- 請勿在駕駛時操作開關。
- 請勿在會妨礙前方視線、駕駛操作或對乘客造成危害的位置安裝本產品。

警示

- 在您連接本產品的電源之前，請確認本產品機體底部或後方所標示的電壓與 12V 車用插座或當地電源電壓是否相同。
- 本產品是針對使用 12V 電池的車輛而設計。請勿用於大型卡車、公車或其他使用 24V 電池的車輛。
- 請勿在拔除車用變壓器或連接插頭時拉扯電源線。
- 請僅使用本產品隨附的電源供應器。





- 運送時，留意勿摔落產品或使其遭受強力衝擊。連續使用產品可能導致火災與觸電。
- 當車用變壓器、插頭、電源線或產品本身受損時，請勿使用本產品。
- 本產品可供 8 歲以上孩童、身體官能或心智能力退化者，或是經驗與使用知識缺乏者使用，但需要有人在旁監督或適當指示如何安全使用本產品，以及可能遭受的危險。請勿讓兒童把玩本產品。若無人在旁監督，不得讓孩童清潔與維護產品。
- 請勿在出風口或進風口放置物品上，而擋住進出風口。
- 請勿將本產品浸入水中。
- 請先切斷電源並從點煙器插座取下車用變壓器，再更換抗病毒蕊盒*、更換活性碳濾網或清潔本產品。
- 當您長時間不使用本產品時，請切斷電源並從點煙器插座取下車用變壓器。
- 如果點煙器插座和煙灰缸是整合式裝置，請在點煙器熄滅後使用本產品。



注意

- 本產品不可用來作為維持良好通風的設備、替代吸塵器清潔，或當作除臭劑使用。
- 如果供應產品電力的電源插座接頭不良，產品插頭會發熱。請確定將產品插入接頭良好的插座。
- 請將本產品放置在乾燥平穩的水平面上使用。
- 在車內使用時，建議您將產品置於汽車的置杯架中。





- 請勿將產品置於市面上販售的置杯架、冷氣口車架或各種不穩定的車用支架中。
- 若產品有掉出置杯架的風險，尤其是在顛簸不平路面駕駛等情況下，請降低車速或事先將產品從置杯架中取出。
- 請勿於產品上堆置任何物品或坐在產品上面。
- 請勿將產品放置在冷氣機正下方，以免冷氣機滴水，造成產品發生水滴凝結的現象。
- 請在開啟產品電源之前，確認活性碳濾網和抗病毒蕊盒皆已正確安裝。
- 請僅使用本產品專用的原廠飛利浦活性碳濾網和抗病毒蕊盒。請勿使用其他產品。
- 切勿使用堅硬的物體敲打產品（特別是進風口及出風口）。
- 請勿將手指或任何物體放入出風口。
- 當您使用室內噴霧式驅蟲劑或在充滿油漬、燒香、香煙的火星或化學煙霧的地方時，請勿使用本產品。
- 請勿在氣體用品、加熱裝置或壁爐附近使用本產品。
- 使用完畢後或進行清潔之前，請務必先拔除電源插頭。
- 請勿在溫差變化極大的室內或車內使用本產品，因為室溫差距太大会造成本產品內部凝結水珠。
- 在家使用時，請將本產品遠離使用無線電電波的電子電器至少 2 公尺以避免干擾，例如電視、無線電廣播、無線電信號控制的時鐘。
- 本產品為家用和車用產品，僅限於在正常操作環境下使用。





- 請勿在極為潮濕或周遭溫度很高的環境下使用本產品，例如浴室、廁所或廚房。
 - 本產品無法清除一氧化碳 (CO) 或氫氣 (Rn)。發生燃燒意外及危險化學物品意外時，本產品無法當作安全裝置使用。
 - 抗病毒蕊盒可能會散發獨特氣味。如果氣味讓您感到不適，請增加空氣流通，例如打開窗戶或停止使用產品。
- * 通過美國 Intertek Institute 的去除 MS2 菌種測試 (在 11 立方公尺的空間進行測試)。





2 您的空氣清淨機

感謝您購買本產品。歡迎來到飛利浦的世界！


請至 www.philips.com/welcome 註冊您的產品，以獲得飛利浦提供的完整支援。

在您安裝和使用本裝置前，請先詳讀本使用手冊。敬請妥善保管本手冊，以供日後參考。



概覽

清點產品零件。



- 
- 
- 
- ① 風速按鈕
 - ② 指示燈按鈕
 - ③ 進風口
 - ④ 底蓋
 - ⑤ 出風口
 - ⑥ 電源線插孔
 - ⑦ 活性炭濾網
 - ⑧ 抗病毒蕊盒
 - ⑨ 刷具
 - ⑩ 交流電/直流電變壓器
 - ⑪ 車用變壓器

3 快速入門

安裝抗病毒蕊盒




本產品隨附所有配件，但您必須先拆下抗病毒蕊盒的包裝，並將抗病毒蕊盒插入產品中才能使用。取下塑膠和 2 張小貼紙，再將其裝入產品中，如下所述。



備註






- 請務必先拔掉清淨機的電源插頭，再安裝抗病毒蕊盒。(圖 1)
- 將匣裝入正確的位置。

- 1 以順時鐘方向旋轉開啟底蓋。(圖 2)
- 2 拆開正面護板蓋。(圖 3)



- 3 在裝入新的匣之前，先取下 2 張小貼紙。(圖 4-6)
- 4 若要重新裝入正面護板蓋，先將頂部扣鉤裝入產品頂部 ❶。然後將護板推入產品機體 ❷。(圖 7)

5 裝上底蓋，並以逆時鐘方向旋轉將其關閉。(圖 8)



連接

車用





注意

- 安裝產品時請勿擋住進出風口。
- 如果您將產品放在冷氣機前面，當車用暖氣機開啟時也會被加熱。請小心不要受傷。



1 將車用變壓器接上電源線插孔。(圖 1)

2 將點煙器插頭接上點煙器插座。(圖 2)



家用或辦公室用

- 1 將交流電/直流電變壓器接上電源線插孔。(圖 1)
- 2 將電源插頭接上電源插座。(圖 2)





開啟電源並變更風速



注意

- 當您關閉引擎或取出車鑰匙時，請拔除點煙器插頭以避免汽車電池放電。




備註

- 如果您在使用空氣清淨機時關閉汽車電源，重新啟動汽車時，清淨機會以第 1 級的風速運作。
- 風速分為 2 級。
- 為了節約能源，空氣清淨機時每隔 8 小時會自動關閉，您需要手動按下風速按鈕打開空氣清淨機。

- 1 按下風速按鈕會開啟空氣清淨機電源。
 - ↪ 空氣清淨機會以第 1 級的風速運作。(圖 1)
 - ↪ 指示燈會自動亮起。若要關閉指示燈，可按下指示燈按鈕將其關閉。(圖 4-5)
- 2 再次按下風速按鈕可提高風速。(圖 2)



3 第三次按下風速按鈕可關閉空氣清淨機電源。(圖 3)



4 清潔空氣清淨機




備註

- 進行清潔前，請務必先拔掉清淨機的電源插頭。
- 切勿讓清淨機浸入水或其他液體中。
- 切勿使用漂白劑或酒精等具磨蝕性、刺激性或易燃洗劑清潔清淨機的任何部分。

定期清潔清淨機機體的內部與外殼，可避免累積灰塵。

- 1 請使用柔軟的乾布擦拭清淨機的機體。
- 2 使用清潔刷清潔進風口及出風口。
 - 使用後，可將清潔刷掛在空氣清淨機內部的側邊。






5 更換抗病毒蕊盒



備註






- 請務必先拔掉清淨機的電源插頭，再更換抗病毒蕊盒。(圖 1)
- 每 3 個月更換一次抗病毒蕊盒。
- 將抗病毒蕊盒裝入正確的位置。

- 1 以順時鐘方向旋轉開啟底蓋。(圖 2)
- 2 拆下正面護板蓋。(圖 3)



- 3 在裝入新的匣之前，先取下塑膠和 2 張小貼紙。(圖 4-6)
- 4 若要重新裝入正面護板蓋，先將頂部扣鉤裝入產品頂部 ①。然後將護板推入產品機體 ②。(圖 7)

5 裝回底蓋，並以逆時鐘方向旋轉將其關閉。(圖 8)



6 更換活性碳濾網






備註




- 在更換活性碳濾網之前，請務必拔除清淨機的電源插頭。(圖 1)
- 活性碳濾網應該每6個月更換一次。
- 將濾網裝入正確的位置。

1 以順時鐘方向旋轉開啟底蓋。(圖 2)

2 取出活性碳濾網。(圖 3)



- 3 拆下濾網的包裝材料，然後插入新濾網。(圖 4-5)
- 4 裝回底蓋，並以逆時鐘方向旋轉將其關閉。(圖 8)



7 疑難排解

本單元概述您使用本產品時可能遇到的最常見問題。如果您無法利用以下資訊解決您遇到的問題，請聯絡您所在國家/地區的客戶服務中心。

問題	可能的解決方法
出風口沒有空氣流出。	• 清淨機沒有連接至電源供應器。請將清淨機接上電源，然後開啟電源。 • 在您連接空氣清淨機的電源之前，請確認空氣清淨機機體底部或後方所標示的電壓與 12V 車用插座或當地電源電壓是否相同。
出風口流出的風速比之前慢很多。	查看濾網的更換週期。視需要加以更換。
出風口發出異味。	• 查看濾網的更換週期。視需要加以更換。 • 抗病毒蕊盒散發獨特氣味。此氣味來自用來去除您周遭室內空氣所含病毒的天然成份。如果您將裝置放在較遠和/或遠離陽光直射的較涼爽位置，您所聞到氣味的強度就會降低。

* 通過美國 Intertek Institute 的去除 MS2 菌種測試 (在 11 立方公尺的空間進行測試)。



8 保固與服務

若您需要相關資訊，或是有任何問題，請造訪飛利浦網站：www.philips.com，或聯絡您所在國家/地區的飛利浦客戶服務中心 (您可在全球保證書上找到電話號碼)。若當地沒有客戶服務中心，請洽詢當地的飛利浦經銷商。

訂購零件或配件

如果您必須更換零件或想購買其他零件，請聯絡您的飛利浦經銷商，或造訪 www.philips.com/support。如果您有取得零件方面的問題，請聯絡您所在國家/地區的飛利浦客戶服務中心 (您可在全球保證書上找到電話號碼)。





9 聲明

電磁場 (EMF)

本飛利浦產品符合所有電磁場暴露的相關適用標準和法規。

符合 EMF 標準

Koninklijke Philips N.V. 製造銷售多項消費性產品，這些產品就如同其他電器，通常能收發電磁訊號。

飛利浦的一大企業原則，就是針對自身的產品進行必要的健康與安全檢測，以符合所有適用的法律規定，以及在產品生產期間符合適用的 EMF 標準。

飛利浦致力於開發、生產及銷售不危害健康的產品。飛利浦保證，只要依照正確用途並妥善使用，根據現有的科學研究資料，使用本公司產品並無安全顧慮。

飛利浦積極參與國際 EMF 與安全標準的開發，因此得以掌握標準化的發展，及早將標準化與自身的產品整合。





回收

本產品使用壽命結束時，請勿與一般家庭廢棄物一併丟棄。請將該產品送至政府指定的回收點或進行回收。此舉能為環保盡一份心力。

請遵循您所在國家/地區對電氣與電子產品分類收集的規定。正確處理廢棄產品有助於避免對環境和人類健康帶來負面影響。



設備名稱：飛利浦空氣清淨機， 型號（型式）：AC4030/80, AC4030/81 Equipment name Type designation (Type)						
單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁶⁺)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
電源線組	—	○	○	○	○	○
塑膠外殼	○	○	○	○	○	○
電源板組件	○	○	○	○	○	○
電動機	—	○	○	○	○	○
主電路板組件	—	○	○	○	○	○
備考1：“超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。 Note 1: “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition. 備考2：“○”係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2: “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence. 備考3：“—”係指該項限用物質為排除項目。 Note 3: The “—” indicates that the restricted substance corresponds to the exemption.						







©2017 Koninklijke Philips N.V.
All rights reserved.

4241 210 17313

