







Digital Video Disc Player & Video Cassette Recorder




- Remote Control
- Batteries (AA, 1.5V x 2)



Audio / Video Cables



Quick Start Guide



User Manual

Need help?

User Manual
 See the user manual that came with your Philips DVD / VCR.
Online
 Go to www.philips.com/support
Hotline
 Call 1-866-309-0846 for our operators.



Philips and Philips Shield are used under license of
 Koninklijke Philips Electronics N.V.
www.philips.com/support



© 2012 P&F USA, Inc.
 PO Box 2248
 Alpharetta, GA 30023-2248


Printed in China
 E8E2BUD/E8E2BUH
 1VMN32774 ★★★★★



1


COMPONENT VIDEO OUT & DVD / AUDIO OUT

DVD




2







1



2




3



S-VIDEO OUT & DVD / AUDIO OUT

DVD



DVD / VCR VIDEO OUT & DVD / VCR AUDIO OUT

DVD / VCR

