





Tefal®


VERSALIO DELUXE









1




2



1




3



4



5




6




7



8




9



10

2




0,5 L




2 L



11



12




13



< 0,5 L



1 L → 2 L




14


3




Deep fry



Max 1000 g




Max 750 g






Deep fry




24




25




26




27




28




29



30



31






32



33



34



5



Deep fry

Deep fry / 180 °C



 2 L maxi			
	1000 g	15-16 min	4
	550 g	10-11 min	
	750 g	13-14 min	
	400 g	7-8 min	



6



Fry

Fry / 160 °C

 0,5 L maxi		
	15 min	4
	30 min	6




7



Sauté

Sauté / 130 °C

x1	10 min	4



8



Simmer

Simmer / 100 °C

30 min	4




9



Boil/Pasta

	
30 min	4




10



Rice/Risotto

	
15 min	4








Braise

	
40 min	4







53




54



55



56





57




58




59







65




66




67




68




69




70



71




72



73



74




75




76



77



78



79

