

PHILIPS

Food processor
bowl

3.4 l

black handle

HR3916



Indispensable part of your food processor

Find matching products on the specifications tab

A bowl, part of your Philips food processor, that allows you to make extra large amounts of, for example, soup or dough in one go. An additional one might be handy: when one's in the dishwasher you can use the other!

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types: HR7774/90

Fits product types: HR7775/00

