

PHILIPS

Water container

New Generation

Blue

CRP469/01



To store the water in your SENSEO@

Please check specifications for compatible products

A water container should be cleaned regularly. Whenever cleaning is required, you'll be happy not to miss your coffee moment and to have an extra tank for your SENSEO@ coffee machine. It has a content of 1.2 litres, for eight cups of coffee.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types: HD7842

