

PHILIPS

Filter for kettle

CRP228



Basket for the tea or teabags in your Teamaker

Check compatibility data

Did you know that green tea needs to be prepared differently from herbal tea? Your Teamaker takes care of it all. The detachable filter basket can be used to put the tea or teabags in.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: To be defined

Fits product type:: HD7310/60

