



Freezer 11 LP


Installation Manual

EN Installation Manual: www.arctic.ac/fileadmin/f11lp/manual_en.pdf
DE Montageanleitung: www.arctic.ac/fileadmin/f11lp/manual_de.pdf
FR Guide d'installation: www.arctic.ac/fileadmin/f11lp/manual_fr.pdf
ES Manual de instalación: www.arctic.ac/fileadmin/f11lp/manual_es.pdf
PT Manual de Instalação: www.arctic.ac/fileadmin/f11lp/manual_pt.pdf
SE Installationsmanual: www.arctic.ac/fileadmin/f11lp/manual_se.pdf

CZ Instalační příručka: www.arctic.ac/fileadmin/f11lp/manual_cz.pdf
HU Telepítési kézikönyv: www.arctic.ac/fileadmin/f11lp/manual_hu.pdf
PL Instrukcja montażu: www.arctic.ac/fileadmin/f11lp/manual_pl.pdf
NL Installatiehandleiding: www.arctic.ac/fileadmin/f11lp/manual_nl.pdf
RU Руководство пользователя: www.arctic.ac/fileadmin/f11lp/manual_ru.pdf
IT Manuale di installazione: www.arctic.ac/fileadmin/f11lp/manual_it.pdf

Accessories

Screw (M3)



x 4


Push pin



x 4




Mounting bracket




x 2

Uninstall Intel stock cooler



Install the Freezer 11 LP



Thermal Compound

Thermal compound is pre-applied to the heat sink of this cooler. If the cooler has to be installed a second time, we highly recommend MX-4 from ARCTIC. This is the only compound that can guarantee optimal performance in combination with the surface of our heat sink.

Warranty

This ARCTIC product includes a six-year limited warranty. Please visit warranty.arctic.ac for further details.

© 2013 ARCTIC (HK) Ltd. All Rights Reserved.

ARCTIC Switzerland AG

www.arctic.ac

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC (HK) Ltd. In no event shall ARCTIC (HK) Ltd. and its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.