

Windows 7/Vista

The screenshot shows the Windows 7/Vista Sound settings. The 'Sound' window is open, and the 'Recording' tab is selected. The 'USB Microphone' is highlighted in the list of recording devices. The 'Microphone Properties' window is also open, showing the 'Levels' tab. The 'Microphone' volume slider is set to 100, and the 'Microphone Boost' is set to +30.0 dB. The 'OK' button is highlighted.

Open Volume Mixer
Playback Devices
Recording Devices
Sounds

USB Microphone

Microphone Properties
Levels
Microphone
Microphone Boost

A B C 2x D

Picture button

The diagram shows a hand pressing the picture button on a webcam. A blue arrow points from the button to the URL www.trust.com/18679/drivers.

www.trust.com/18679/drivers

Frequently Asked Questions
<http://www.trust.com/18679/faq>

© 2016 Trust International B.V. - All rights reserved
Laan van Barcelona 600
3317DD, Dordrecht, NL


Trust
HD 720P
Webcam

TRINO

Quick Installation Guide

The image shows the Trust HD 720P Webcam, which is a black webcam with a flexible neck and a coiled cable. It is shown from a front-three-quarter view, reflecting on the surface below it.

1.



2.

