

Philips GoGear MP4 player

SA2VBE04
SA2VBE08
SA2VBE16

Quick start guide

Przewodni szybkiego startu

Guía de inicio rápido

Snabbstartsinstruktioner

Schnellstartanleitung

Quick start guide

Stručný návod k rychlému použití

คู่มือเริ่มต้นใช้งานอย่างย่อ 快速入门指南

Guide de démarrage rapide

Handleiding voor snel gebruik



快速入門指南 Hızlı Başlama Kılavuzu

Guida di riferimento rapido

Быстрый запуск


Guia para início rápido

PHILIPS





 2000 / XP / Vista / 7





2



XP

Vista

PHILIPS


Philips Songbird







3






4






















Be responsible
Respect copyrights

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners

© 2010 Koninklijke Philips Electronics N.V.

All rights reserved.

www.philips.com



Printed in China
wk10084

SA2VBE_00_QSG_V1.0