






ES Imprima el manual de usuario en www.philips.com/support.

PHILIPS


1




2
☆☆☆




2
☆☆☆




1



3




4




2


1



2




3




3


1




2



3




4




3


1




2




3




1




2



1



2



© 2011 Koninklijke Philips Electronics N.V.
All rights reserved.
<http://www.philips.com>

MCD183_77_QSG_V2.2

