



Philips
Toaster oven

700-750 W



HD4494

Delicious hot food easily

30 minutes timer

A toaster oven designed to help you make delicious food and snacks every time. Toasts and warms, and has a lot of features that make it easy to get good food.

Ideal for cooking different snacks

- Toasts or warms food and snacks
- Adjustable temperature control for optimal result
- Large baking tray for cooking different foods
- 700-750W high power

Simple design with clear indication

- On/off light shows status clearly
- Ready bell sounds when food is ready

The ultimate in convenience

- 30-minute timer shuts off the oven once ready
- Detachable rack for easy handling
- Non stick coating tray for easy cleaning

PHILIPS

Specifications

General specifications

- Temperature control
- Baking tray
- On/off light
- Ready signal
- 30-minute timer
- 45-minute timer
- Detachable rack
- Non stick tray
- 9L capacity

Design specifications

- Available color(s): Silver/Grey

- Color(s): Silver/Grey
- Product dimensions (L x W x H): 30 x 36.3 x 17.9 cm

Technical specifications

- Power: 750W (Argentina), 700 W
- Capacity: 9 L
- Voltage: 220 V
- Frequency: 50/60 Hz
- Cord length: 0.9 m

Accessories included

- Baking tray: 245.5 (L) x 208.5 (W) x 20.8 (H) mm

Highlights

Toasts or warms food

Good for toasting , browning/crisping, defrosting, grilling and baking different food.

Adjustable temperature control

80-230C adjustable, use the temperature selector to set the required cooking temperature.

Large baking tray

Capacity: 9L; can grill chicken meat or to defrost mini-pizzas

700-750W high power

Good for cooking different food

On/off light



Clearly indicate the status

Ready bell sounds

Clearly indicate the cooking status.

30-minute timer

Easy to preset cooking and ready on time.

Detachable rack

Convenient and safe to handle different cooking.

Non stick coating tray

Durable and easy to clean

