

Philips GoGear MP3 player

SA2RGA02
SA2RGA04
SA2RGA08

Quick start guide

Przewodni szybkiego startu

Guía de inicio rápido

Snabbstartsinstruktioner

Schnellstartanleitung

Quick start guide

Stručný návod k rychlému použití

คู่มือเริ่มต้นใช้งานอย่างย่อ 快速入门指南

Guide de démarrage rapide

Handleiding voor snel gebruik



快速入門指南 Hızlı Başlama Kılavuzu

Guida di riferimento rapido

Быстрый запуск

Guia para início rápido

PHILIPS



 2000 / XP / Vista / 7







500Mb



www

1





PHILIPS


Philips Songbird



3



4











Be responsible
Respect copyrights

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or
their respective owners

© 2010 Koninklijke Philips Electronics N.V.

All rights reserved.

www.philips.com



Printed in China
wk10062

SA2RGA_00_QSG_V1.0