


What's in the box



Handset



2 AAA battery



Battery door



Charger



Base station



Installation CDROM



Quick start guide



2 Power supply units



Line cord

In multipack sets you will find additional handsets, chargers with their power supply and additional rechargeable batteries.

What else will you need



A desktop or a laptop with free USB port




A telephone line

Internet connection (broadband recommended)

Skype installed on your PC and a Skype account (use the Skype version provided on the installation CD for the handset to work properly)

I Install

A Connect to main supply



- Insert the plug of the power cord into the socket on the bottom of the base unit
- Plug the power supply unit into your power outlet.

B Install the software



- Insert the installation CD into the PC's CD ROM (or DVDROM) drive
- The installation program will start automatically
- Follow instructions on the screen.

During the installation you will be asked to:

Connect USB plug



- Connect the USB plug directly to your PC's USB slot.

Go on following instructions on the screen.

C Finish installation




- Click on **Quit**.
- Remove the installation CD from the PC's CDROM drive.

Use the Skype version provided on the installation CD for the handset to work properly.

2 Connect

Once the drivers and software installed !

A Connect the line



You may find in the box the line adaptor. In this case, first plug this line adaptor onto the line cord before connecting it to the line socket.

- Connect the telephone line cord to the phone socket on the bottom of the base unit and to the wall phone socket.

C Connect the charger



- Insert the plug of the power cord into the socket on the bottom of the charger
- Plug the power supply unit into your power outlet

D Charge handset



- Before first use, put the handset on the charger and charge batteries for 24 hours minimum.
- To set the language of your handset, press any key when you see **WELCOME**
- Select your country and press **OK**

B Insert batteries



- Place the 2 rechargeable NiMH AAA batteries, observing their polarities, into the battery compartment on the handset.
- Slide the battery door firmly into place.

3

Enjoy

Skype calls

A Make and answer calls



- Press the Skype key to access your Skype Contacts list.
- Press to select the Skype user
- Press or to call the selected contact.

On a Skype incoming call, will flash on the display and Skype ID will be displayed.

- Press the line key to answer the call.

To end a call press or place the phone on the charger.

B Use the contacts list



The contacts list shows the Skype contacts list of the user currently logged in to Skype on the PC.

- Press the Skype key to access your Skype Contacts list.
- Use to select the Skype user.
- The symbol ">" placed before the contact name indicates that this entry is selected if you press OK.

C User status display

- Online / SKYPE ME
- Offline
- Away
- Not available
- Not disturb
- Invisible
- SkypeOut entry

The icon of the left of each entry shows the online status of that entry.
Refer to the left table for the description of each status.

Landline calls

A Make and answer calls



- Press the line key and enter the number to make a call.
OR
- Enter the number you want to call and press the line key to make a call.
- Press the line key to answer a call.

To end a call press or place the phone on the charger.

Welcome

Quick Start Guide

1

Install

2

Connect

3

Enjoy



PHILIPS