



5.3




5.4





REMOVE TV FROM FLOOR STAND

- Fernsehgerät vom Standfuß nehmen
- Retirez la télévision du pied de sol
- TV verwijderen van vloerstandaard
- Quite el televisor del soporte de suelo
- Rimuovere la TV dal piedistallo
- Retire a TV do suporte de chão
- Avlägsna TV:n från golvstativet
- Zdejmij telewizor ze stojaka podłogowego
- Снять телевизор с подставки

- Odstraňte televízi z podlahového stojanu
- Odstráňte televizor z podlahového stojana
- A TV eltávolítása a padlóállványról
- TV'yi zemin desteginden çıkartın
- Scoateți televizorul din suportul de podea
- Зніміть телевізор з підставки
- Свалете телевизора от подовата стойка
- フロア・スタンドからテレビを取り外す



OPTIONAL POSITIONS



vogel's®

Mounting instructions
Montageanleitung
Consignes d'installation
Montagevoorschrift
Instrucciones de montaje
Istruzioni di montaggio

Manual de montagem
Montageföreskrifter
Instrukcja montażu
Инструкция по сборке и установке
Návod k montáži

Návod na montáž
Szerelési előírás
Montaj kılavuzu
Instrucțiuni de montaj
Вказівки по монтажі
設置の説明書



1

2

3


4

5


MOUNTING INSTRUCTIONS

Visit www.vogels.com for more information

PARTS INCLUDED



TOOLS REQUIRED NOT INCLUDED



EFF 8340



Important
Wichtig
Important
Belangrijk
Importante
Importante
Importante
Viktigt
Ważne
Важно
Důležité
Dôležité
Fontos
Önemli
Important

Для монтажу необхідно 2 людини Important

Важливо
重要



2 persons required
Zwei Personen erforderlich
Nécessite deux personnes
2 personen
Se precisan dos personas
E' richiesta la presenza di due persone
Requer duas pessoas
Två personer erfordras
Konieczne dwie osoby
Нужны два человека
Montáž vyžaduje 2 osoby
Montáž vyžaduje 2 osoby
Két személy szükséges
Íki kişi gerekli
Este nevoie de două persoane
Для монтажу необхідно 2 людини
Необходими са двама души
二人作業



MADE IN THE NETHERLANDS
VOGEL'S PRODUCTS BV
NL 5628 DB EINDHOVEN
WWW.VOGELS.COM

