



What's in the box




Handset




2 AAA battery



Charger




Base station



CDROM



Quick start guide



2 Power supply units




Line cord (and line adaptor if relevant)

In multipack sets you will find additional handsets, chargers with their power supply and additional rechargeable batteries.

What else will you need



A desktop or a laptop with free USB port




A telephone line

Broadband Internet connection.
Microsoft® Windows® XP-based PC.
Windows Live™ Messenger installed on your PC and a Windows Live™ Messenger account. See <http://get.live.com/messenger/overview>
Note: Microsoft Internet Explorer version 6 SP1 or later must be installed on your PC, though it does not need to be your default browser.


1 Connect

A Connect to main supply




- Insert the plug of the power cord into the socket on the bottom of the base unit.
- Plug the power supply unit into your power outlet.

C Insert batteries



- To remove the battery compartment, unlock the battery door lock at the bottom of the handset.
- Place the 2 rechargeable NiMH AAA batteries, observing their polarities, into the battery compartment on the handset.
- Slide the battery door firmly into place until the battery door locks.


B Connect the line



You may find in the box the line adaptor. In this case, first plug this line adaptor onto the line cord before connecting it to the line socket.

- Connect the telephone line cord to the phone socket on the back of the base unit and to the wall phone socket.

D Connect the charger



- Insert the plug of the power cord into the socket on the bottom of the charger.
- Plug the power supply unit into your power outlet.

E Charge handset




Handset may not turn ON for up to 15 minutes if the batteries are too low.

- Before first use, put the handset on the charger and charge batteries for 24 hours minimum.

2 Install

A Getting ready



- Power up your PC and go to <http://get.live.com/messenger/overview> to install Windows Live™ Messenger and create your account (if not already done).
- Connect the USB plug directly to your PC's USB slot.
- Once your handset is powered up, you will see WELCOME message on the display.
- Press any key to enter the Country menu.
- Press **Up** or **Down** to select your country. Press OK to confirm.
- Your phone will reset after OK is pressed.


3

Enjoy

Windows Live™ Messenger calls


A Sign in to your Windows Live™ Messenger account

- To be able to sign in to Windows Live™ Messenger from your handset, you must have automatically saved on your PC the email address and password of the account you wish to use.
- Before being able to make a Windows Live™ Messenger call on your handset, you must have signed into one of your Windows Live™ Messenger accounts on your PC or via your handset.



- Press . If you have not sign in yet, the Sign In screen is shown. A list of Messenger users on PC with saved passwords will be shown.
- Press **Up/Down** to select the Messenger ID to sign in to.
- Press **SIGN IN**
> Once signed in, the contact list of the signed in user will be shown.

B Make and answer calls



- Press . The contact list will be shown.
- Press **Up/Down** to select the Windows Live™ Messenger user you would like to call
- Press **SELECT** to select the contact
- Press **Up/Down** to select the user's Messenger ID
- Press **PC** to call the user
- Press to answer the call.

To end a call, press or place the phone on the charger.


C User status display

- Online
- Busy
- Be right back
- Away
- In a call
- Out to lunch
- Appear offline

The icon on the left of each entry shows the online status of that entry. Refer to the left table for the description of each status.

Landline calls

A Make and answer calls



- Press and enter the number to dial.
OR
- Enter the number you want to call and press to dial the number.
- Press to answer a call.

To end a call, press or place the phone on the charger.

Need help ?

User manual : See the user manual that came on the included CDROM

Online help : www.p4c.philips.com

Updated informations for Users are available on: www.p4c.philips.com

Welcome

Quick start guide

1

Connect

2

Install

3

Enjoy



PHILIPS