



Philips GoGear MP4 player

SA2CAM04
SA2CAM08
SA2CAM16

Quick start guide

Przewodni szybkiego startu
Guía de inicio rápido
Snabbstartsinstruktioner
Schnellstartanleitung
Quick start guide
Stručný návod k rychlému použití
คู่มือเริ่มต้นใช้งานอย่างย่อ 快速入门指南
Guide de démarrage rapide
Handleiding voor snel gebruik
快速入門指南 Hızlı Başlama Kılavuzu
Guida di riferimento rapido
Быстрый запуск
Guia para início rápido

PHILIPS




 2000 / XP / Vista / 7






500Mb



www



2



PHILIPS


Philips Songbird





3








4





















Be responsible
Respect copyrights

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or
their respective owners

© 2010 Koninklijke Philips Electronics N.V.

All rights reserved.

www.philips.com



Printed in China

wk10256

SA2CAM_02N_QSG_V1.1