



Philips
CD Soundmachine

- Lifestyle design
- USB

AZ1837/55

Enjoy your music wherever you go

Handy lifestyle design, enjoy music from different sources like USB Direct, MP3-CD, radio.

Benefits

Enjoy your music from different sources

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- FM/MW tuner for radio enjoyment

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

Features

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

PHILIPS

Play MP3/WMA-CD, CD and CD-RW




Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Specifications

[field not found 'disclaimer_text']

Audio playback

Playback media	CD CD-R CD-RW MP3-CD WMA-CD
Disc playback modes	fast forward/backward next/previous track search repeat/shuffle/program
USB Direct playback modes	fast backward/fast forward previous/next program play shuffle

Speaker grille finishing	metal
--------------------------	-------

Convenience

Loader type	top
Display type	LCD display

Accessories

Cables/Connection	3.5 mm stereo line in cable power cord
Others	User Manual
Warranty	Warranty Certificate

Connectivity

USB	USB host
MP3 Link	3.5mm stereo line in

Power

Battery type	C size (LR14)
Battery voltage	1.5 V
Power supply	110 - 127V and 220 - 240V AC voltage selectable
Number of batteries	6

Tuner/Reception/Transmission

Tuner bands	FM MW
Antenna	FM antenna

Dimensions

Gross weight	2.4 kg
Packaging depth	139 mm
Packaging height	262 mm
Packaging width	371 mm
Weight	1.8 kg
Main unit depth	236 mm
Main unit height	122 mm
Main unit width	341 mm

Sound

Sound system	stereo
Volume control	rotary (analogue)
Output power	2 x 1 W RMS

Loudspeakers

No. of built-in speakers	2
--------------------------	---



data subject to change
2015, April 10

Version: 1.0.5
EAN: 8712581522469

© 2015 Koninklijke Philips Electronics N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com