



Philips
Remote control

RC4720

To operate your device from a distance

Check compatibility data

For fast and easy control of your device. Is your old remote control lost or broken? Order a new one here! Delivered without batteries.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types:: 14HT3154/01, 14HT3154/05, 14HT3304/01, 14HT3304/05, 15HF8442/12, 17HT3154/01, 17HT3304/01, 17HT3304/05, 20HF7462/12, 21HT3304/01, 21HT3304/05, 21HT3312/69R, 21HT3312/79R, 21HT3504/01, 21HT3504/05, 23HF9442/98, 23HF9472/12, 25HT3312/69R, 25HT3312/79R, 25HT3312/93R, 25HT3317/69Y, 25HT3317/79Y, 25HT3317/93Y,

25HT5541/77S, 25HT5541/78S, 26HF9472/12, 29HT3312/69R, 29HT3312/93R, 29HT3317/69Y, 29HT3317/79Y, 29HT3317/93Y, 29HT4641/78S, 29HT5642/77S, 29HT5642/78S, 30HF9442/12, 30HF9442/98, 34HT3312/93R, 42HF9442/12, 42HF9442/98

- Fits product type:: 23HF9442/98
- Fits product types:: 21HT3154/01

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2020-06-02

Version: 2.0.1

EAN: 08 71010 35564 66

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com