






















Register your product and get support at
www.philips.com/welcome

FC8619 - FC8600



PHILIPS





ENGLISH 6

한국어 11

繁體中文 16

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Never suck up water or any other liquid. Never suck up flammable substances and do not suck up ashes until they are cold.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not point the hose, the tube or any other accessory at the eyes or ears nor put it in your mouth when it is connected to the vacuum cleaner and the vacuum cleaner is switched on.

Caution

- When you use the vacuum cleaner to vacuum ashes, fine sand, lime, cement dust and similar substances, the pores of the dustbag become clogged. As a result, the dustbag-full indicator will indicate that the dustbag is full. Replace the disposable dustbag and empty the reusable dustbag, even if it is not full yet (see chapter 'Replacing/emptying the dustbag').
- Never use the appliance without the motor protection filter. This could damage the motor and shorten the life of the appliance.
- Only use Philips s-bag™ synthetic dustbags or the reusable dustbag provided (some countries only).

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Preparing for use

Hose

- 1 To connect the hose, push it into the appliance (1) and turn it clockwise (2) (Fig. 1).
- 2 To disconnect the hose, turn it anticlockwise (1) and pull it out of the appliance (2) (Fig. 2).

Tube

There are two types of coupling systems. This appliance is equipped with one of them. The coupling systems are shown in the following figures.

Conical coupling (specific types only)

- 1 To connect the tube parts to each other and to the handgrip of the hose, insert the narrow section into the wider section while turning a little (Fig. 3).

- 2 To disconnect the tube parts from each other and from the handgrip of the hose, pull while turning a little.

Button coupling (specific types only)

- 1 To connect the tube to the handgrip of the hose, press the spring-loaded lock button on the handgrip and insert the handgrip into the tube. Fit the spring-loaded lock button into the opening in the tube ('click') (Fig. 4).
- 2 To disconnect the tube from the handgrip of the hose, press the spring-loaded lock button and pull the handgrip out of the tube.

Note: Use the same method to connect and disconnect the nozzles.

Telescopic tube (specific types only)

- 1 Adjust the tube to the length you find most comfortable during vacuum cleaning (Fig. 5).

Tri-Active nozzle (specific types only)

The Tri-Active nozzle is a multi-purpose nozzle for carpets and hard floors.

- The side brushes catch more dust and dirt at the sides of the nozzle and allow you to clean better along furniture and other obstacles (Fig. 6).
- The opening at the front of the nozzle allows you to suck up larger particles (Fig. 7).

- 1 To clean hard floors, push the rocker switch on top of the nozzle with your foot (Fig. 8).
 - ▶ The brush strip for cleaning hard floors comes out of the housing. At the same time, the wheel is lifted to prevent scratching and to increase manoeuvrability.
- 2 To clean carpets, push the rocker switch again (Fig. 9).
 - ▶ The brush strip disappears into the nozzle housing and the wheel is lowered automatically.

Combination nozzle (specific types only)

The combination nozzle can be used on either carpets or hard floors.

- 1 To clean hard floors, push the rocker switch on top of the nozzle with your foot (Fig. 10).
 - ▶ The brush strip for cleaning hard floors comes out of the nozzle housing.
- 2 To clean carpets, push the rocker switch again (Fig. 11).
 - ▶ The brush strip disappears into the nozzle housing.

Crevice tool and small nozzle

- 1 Connect the crevice tool (1) or small nozzle (2) directly to the handgrip or to the tube (Fig. 12).

Accessory clip

- 1 Snap the accessory clip onto the tube (Fig. 13).
- 2 Snap the crevice tool and the small nozzle onto the clip.

Using the appliance

- 1 Pull the cord out of the appliance and put the mains plug in the wall socket.
- 2 Press the on/off button on top of the appliance with your foot to switch on the appliance (Fig. 14).
- 3 During vacuum cleaning, you can adjust the suction power with:
 - the slide on the handgrip (specific types only) (Fig. 15)
 - the knob on top of the appliance (specific types only) (Fig. 16)

- 4 If you want to pause for a moment, insert the ridge on the nozzle into the parking slot to park the tube in a convenient position (Fig. 17).

Storage

- 1 Switch off the appliance and remove the mains plug from the wall socket.
- 2 Press the cord rewind button to rewind the mains cord (Fig. 18).
- 3 Put the appliance in upright position. To attach the nozzle to the appliance, insert the ridge into the storage slot (Fig. 19).
- 4 Always put the Tri-Active nozzle in the carpet setting when you store it. Also prevent the side brushes from becoming bent (Fig. 9).

Replacing/emptying the dustbag

Always unplug the appliance before you replace the disposable dustbag or empty the reusable dustbag.

Replacing the disposable dustbag

- Replace the dustbag as soon as the dustbag-full indicator has changed colour permanently, i.e. even when the nozzle is not placed on the floor (Fig. 20).

- 1 Pull the cover upwards to open it (Fig. 21).
- 2 Lift the dustbag holder out of the appliance (Fig. 22).

Make sure you hold the dustbag upright when you lift it out of the appliance.

- 3 Pull at the cardboard tag to remove the full dustbag from the holder (Fig. 23).
 ▶ When you do this, the dustbag is sealed automatically.
- 4 Slide the cardboard front of the new dustbag into the two grooves of the dustbag holder as far as possible (Fig. 24).
- 5 Reinsert the dustbag holder into the vacuum cleaner (Fig. 25).

Note: If no dustbag has been inserted, you cannot close the cover.

Emptying the reusable dustbag (some countries only)

In some countries, this vacuum cleaner also comes with a reusable dustbag that can be used and emptied repeatedly. You can use the reusable dustbag instead of disposable dustbags.

To remove and insert the reusable dustbag, simply follow the instructions in 'Replacing the disposable dustbag'.

To empty the reusable dustbag:

- 1 Slide the clip off the dustbag sideways.
- 2 Shake out the contents into a dustbin.
- 3 To close the dustbag, slide the clip back onto the bottom edge of the dustbag.

Cleaning and maintenance of filters

Always unplug the appliance before you clean or replace the filters.

Permanent motor protection filter

Clean the permanent motor protection Filter every time you replace the dustbag.

- 1 Remove the dustbag holder with the dustbag (Fig. 22).

- 2** Take the motor protection filter holder out of the appliance. Take the filter out of the holder (Fig. 26).
- 3** Shake the filter over a dustbin to clean it.
- 4** Reinsert the filter into the holder with the white side pointing towards the dustbag compartment. Press the holder down firmly to make sure that it fits properly at the bottom (Fig. 27).
- 5** Place the dustbag holder with the dustbag back into the appliance (Fig. 25).

Super Clean Air filter (specific types only)

The Super Clean Air filter located in the back of the appliance filters a large part of the smaller particles from the exhaust air with its electrostatically charged fibres.
Replace the Super Clean Air filter every six months.

- 1** Open the filter grille (Fig. 28).
- 2** Remove the old filter.
- 3** Insert the new filter into the appliance (Fig. 29).
- 4** Close the filter grille ('click') (Fig. 30).

Washable Super Clean Air HEPA 12 filter (specific types only)

Instead of with the Super Clean Air filter, some types are equipped with the washable Super Clean Air HEPA 12 filter. This filter is able to remove 99.5% of all particles down to 0.0003mm in size from the outlet air. This not only includes normal house dust, but also harmful microscopic vermin such as house dust mites and their excrements, which are well-known causes of respiratory allergies. Clean the Super Clean Air HEPA 12 filter every 6 months. You can clean the washable Super Clean Air HEPA 12 filter max. 4 times. Replace the filter after it has been cleaned 4 times.

- 1** Open the filter grille (Fig. 28).
- 2** Take out the washable HEPA 12 filter.
- 3** Rinse the pleated side of the HEPA 12 filter under a hot slow-running tap.
 - Hold the filter in such a way that the pleated side points upwards and the water flows parallel to the pleats. Hold the filter at an angle so that the water washes away the dirt inside the pleats (Fig. 31).
 - Turn the filter 180° and let the water flow along the pleats in opposite direction (Fig. 32).
 - Continue this process until the filter is clean.

Never clean the washable filter with a brush (Fig. 33).

Note: Cleaning does not restore the original colour of the filter, but does restore its filtration power.

- 4** Carefully shake the water from the surface of the filter. Let the filter dry at least 2 hours before you put it back into the vacuum cleaner.
- 5** Place the filter back behind the brackets. Make sure that the Philips logo on the filter is visible in the upper left hand corner (Fig. 29).
- 6** Close the filter grille ('click') (Fig. 30).

Ordering accessories

If you have any difficulties obtaining dustbags, filters or other accessories for this appliance, please contact the Philips Customer Care Centre in your country or consult the worldwide guarantee leaflet.

Ordering dustbags

- Philips Classic s-bag TM synthetic dustbags are available under type number FC8021.
- Philips Clinic s-bag TM high filtration synthetic dustbags are available under type number FC8022.
- Philips Anti-odour s-bag TM synthetic dustbags are available under type number FC8023.

Ordering filters

- Super Clean Air filters are available under type number FC8032.
- Non-washable Super Clean Air HEPA 12 filters are available under type number FC8044.
- Washable Super Clean Air HEPA 12 filters are available under service number 4322 000 39090

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 34).

Guarantee & service

If you need information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Customer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Customer Care Centre in your country, go to your local Philips dealer or contact the Service Department of Philips Domestic Appliances and Personal Care BV.

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Customer Care Centre in your country.

1 The suction power is insufficient.

A Check if the dustbag is full.

If necessary, replace the disposable dustbag or empty the reusable dustbag (some countries only).

B Check if the filters need to be cleaned or replaced.

If necessary, clean or replace the filters.

C Check if the suction power knob is in maximum position and/or the slide on the handgrip is closed.

D Check if the nozzle, tube or hose is blocked up (Fig. 35).

- To remove the obstruction, disconnect the blocked-up item and connect it (as far as possible) the other way around. Switch on the vacuum cleaner to force the air through the blocked-up item in opposite direction.

제품 소개

필립스 제품을 구입해 주셔서 감사합니다! 필립스가 드리는 지원 혜택을 받으실 수 있도록 www.philips.com/welcome에서 제품을 등록하십시오.

중요사항

본 제품을 사용하기 전에 이 사용 설명서를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

- 물, 다른 용액 또는 가연성 물질은 절대 흡입하지 마십시오. 타고 남은 재는 완전히 꺼지기 전까지 절대 흡입하지 마십시오.

경고

- 제품에 전원을 연결하기 전에, 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오.
- 만약 플러그나 전원 코드 또는 제품이 손상되었을 경우에는 제품을 사용하지 마십시오.
- 전원 코드가 손상된 경우, 안전을 위해 필립스 서비스 센터 또는 필립스 서비스 지정 점에 의뢰하여 교체하십시오.
- 신체적인 감각 및 정신적인 능력이 떨어지거나 경험과 지식이 풍부하지 않은 사용자(어린이가 포함)는 혼자 제품을 사용하지 말고 제품 사용과 관련하여 안전에 책임 질 수 있도록 지시사항을 충분히 숙지한 사람의 도움을 받으십시오.
- 어린이가 제품을 가지고 놀지 못하도록 지도해 주십시오.
- 호스, 연장관 또는 기타 액세서리가 진공 청소기가 연결되어 있고 진공 청소기의 전원이 켜져 있을 때 이를 눈, 귀에 갖다 대거나 입에 넣지 마십시오.

주의

- 진공 청소기를 사용하여 재, 미세한 모래, 석회, 시멘트 가루 및 유사한 물질을 청소하면 먼지 봉투 구멍이 막히게 됩니다. 이로 인해 먼지 봉투 교체 표시등에 먼지 봉투가 가득 찬 것으로 표시됩니다. 먼지 봉투가 가득 차지 않은 경우에도 먼지 봉투를 교체하십시오(‘교체’란 참조).
- 모터 보호 필터 없이 제품을 사용하지 마십시오. 모터가 손상되고 제품의 수명이 단축될 수 있습니다.
- 반드시 제품과 함께 제공되는 필립스 S-bag™ 합성섬유 먼지 봉투 또는 재사용 먼지 봉투를 사용하십시오(특정 모델만 해당).

EMF(전자기장)

이 필립스 제품은 EMF(전자기장)와 관련된 모든 기준을 준수합니다. 이 사용 설명서의 지침에 따라 적절하게 취급할 경우 이 제품은 안전하게 사용할 수 있으며 이는 현재까지의 과학적 증거에 근거하고 있습니다.

사용 전 준비

호스

- 1 호스를 연결하려면 (1)호스를 제품 안으로 밀어 넣고 (2)시계 방향으로 돌리십시오 (그림 1).
- 2 호스를 분리하려면 (1)호스를 시계 반대 방향으로 돌리고 (2)제품에서 호스를 잡아당겨 빼십시오 (그림 2).

연장관

다음과 같은 두 가지 커플링 시스템이 있습니다. 이 제품은 두 가지 중 하나가 내장되어 있습니다. 커플링 시스템은 다음의 그림에 나타나 있습니다.

12 한국어

원뿔형 커플링(특정 모델만 해당)

- 1 연장관과 손잡이를 서로 연결하려면 연장관을 살짝 돌리면서 좁은 부분을 넓은 부분에 끼우십시오 (그림 3).
- 2 연장관과 손잡이를 분리하려면 살짝 돌리면서 잡아당겨 빼십시오.

버튼 결합 기능(특정 모델만 해당)

- 1 호스 손잡이에 연장관을 연결하려면 손잡이에 있는 스프링식 잠금 버튼을 누르고 손잡이를 연장관에 끼우십시오. 스프링식 잠금 버튼을 연장관 구멍에 맞추십시오(‘찰칵’ 소리가 남) (그림 4).
- 2 호스의 손잡이에서 연장관을 분리하려면 스프링식 잠금 버튼을 누르고 연장관에서 손잡이를 잡아당기십시오.

참고: 노즐을 연결하고 분리할 때에도 같은 방법을 사용하십시오.

길이 조절이 가능한 연장관(특정 모델만 해당)

- 1 진공 청소기를 사용하는 동안 연장관을 사용하기 편한 길이로 조절하십시오 (그림 5).

Tri-Active 노즐(특정 모델만 해당)

Tri-Active 노즐은 카페트 및 일반 바닥에서 사용할 수 있는 다용도 노즐입니다.

- 노즐 옆 부분의 측면 브러시는 먼지와 더러움을 더 잘 잡아주며, 가구 및 기타 장애물의 가장자리를 따라 효과적으로 청소합니다 (그림 6).
- 노즐 앞 부분의 구멍은 더 큰 입자를 흡입할 수 있습니다 (그림 7).

- 1 일반 바닥재를 청소하려면 노즐 상단의 로커 스위치를 발로 누르십시오 (그림 8).
▶ 그러면 일반 바닥재용 브러시의 솔 부분이 외장 바깥으로 나옵니다. 동시에 바퀴도 올라가서 굽힘을 방지하고 더 잘 움직이게 됩니다.
- 2 카페트를 청소하려면 로커 스위치를 다시 누르십시오. (그림 9)
▶ 브러시의 솔 부분이 노즐 외장 안으로 들어가고 바퀴도 자동으로 내려옵니다.

콤비네이션 노즐(특정 모델만 해당)

콤비네이션 노즐은 카페트나 일반 바닥에서 사용할 수 있습니다.

- 1 일반 바닥재를 청소하려면 노즐 상단의 로커 스위치를 발로 누르십시오 (그림 10).
▶ 일반 바닥재용 브러시의 솔 부분이 노즐 외장 바깥으로 나옵니다.
- 2 카페트를 청소하려면 로커 스위치를 다시 누르십시오 (그림 11).
▶ 브러시의 솔 부분이 노즐 외장 안으로 들어갑니다.

틈새 노즐 및 소형 노즐

- 1 (1)틈새 노즐 또는 (2)소형 노즐을 손잡이나 튜브에 직접 연결하십시오 (그림 12).

액세서리 클립

- 1 액세서리 클립을 연장관 위에 끼우십시오 (그림 13).
- 2 틈새 노즐과 소형 노즐을 클립 위에 끼우십시오.

제품 사용

- 1 제품에서 코드를 꺼내고 벽면 콘센트에 전원 플러그를 꽂으십시오.
- 2 제품 상단의 전원 버튼을 발로 눌러서 전원을 켜십시오 (그림 14).
- 3 청소 중에도 다음을 사용해 흡입력을 조절할 수 있습니다.
 - 손잡이에 있는 슬라이드(특정 모델만 해당) (그림 15).

- 제품 상단의 조절기(특정 모델만 해당) (그림 16)

- 4 청소로 잠시 중단하려면 노즐 걸이를 임시 보관용 홈에 끼워서 연장관을 편안하게 세워두십시오 (그림 17).

보관

- 1 제품 전원을 끄고 벽면 콘센트에서 전원 플러그를 뽑으십시오.
- 2 코드 되감기 버튼을 눌러 전원 코드를 되감으십시오 (그림 18).
- 3 제품을 똑바로 세워놓으십시오. 노즐 걸이를 보관 홈에 끼워서 노즐을 제품에 부착하십시오 (그림 19).
- 4 청소기를 보관할 때는 Tri-Active 노즐을 항상 카페트 설정에 두십시오. 또한 측면 브러시가 휘어지지 않도록 하십시오 (그림 9).

먼지 봉투 교체/비우기

교체형 먼지 봉투를 교체하거나 재사용이 가능한 먼지 봉투를 비우기 전에 항상 전원 플러그를 뽑으십시오.

교체형 먼지 봉투를 교체

- 먼지 봉투 교체 표시등의 색깔이 바뀌면 즉시 먼지 봉투를 교체하십시오(예를 들어, 노즐을 바닥에 대고 있지 않은 경우도 해당) (그림 20).
- 1 먼지 봉투를 열려면 덮개를 위로 올리십시오 (그림 21).
 - 2 제품에서 먼지 봉투 거치대를 들어내십시오 (그림 22).
- 제품에서 먼지 봉투를 들어올릴 때 똑바로 세워서 잡으십시오.
- 3 거치대에서 가득 찬 먼지 봉투를 분리하려면 딱딱한 판지의 손잡이를 당기십시오 (그림 23).
- ▶ 이렇게 하면 먼지 봉투가 자동으로 밀봉됩니다.
- 4 새 먼지 봉투의 판지 앞면을 먼지 봉투 거치대의 2개 홈으로 최대한 밀어 넣으십시오. (그림 24)
 - 5 먼지 봉투 거치대를 진공 청소기에 다시 끼우십시오 (그림 25).

참고: 먼지 봉투가 끼워져 있지 않으면 덮개를 닫을 수 없습니다.

재사용이 가능한 먼지 봉투 비우기(일부 국가만 해당)

일부 국가에서는 반복해서 사용하고 비울 수 있는 재사용이 가능한 먼지 봉투가 이 진공 청소기와 함께 제공됩니다. 교체형 먼지 봉투 대신 재사용이 가능한 먼지 봉투를 사용할 수 있습니다.

재사용이 가능한 먼지 봉투를 끼우고 뺄 때에는 ‘교체형 먼지 봉투를 교체’에 있는 지침을 따르십시오.

재사용이 가능한 먼지 봉투를 비우려면:

- 1 클립을 먼지 봉투를 옆으로 미십시오.
- 2 내용물을 휴지통에 털어 버리십시오.
- 3 클립을 다시 먼지 봉투 아래 가장자리로 밀어서 먼지 봉투를 닫으십시오.

필터 청소 및 유지관리

필터를 청소하거나 교체하기 전에는 항상 제품 코드를 뽑으십시오.

영구 모터 보호 필터

먼지 봉투를 교체할 때마다 영구 모터 보호 필터를 청소하십시오.

- 1 먼저 봉투가 들어있는 먼지 봉투 거치대를 분리하십시오 (그림 22).
- 2 제품에서 모터 보호 필터 거치대를 꺼내십시오. 필터를 거치대에서 꺼내십시오 (그림 26).
- 3 휴지통 위에서 필터를 털어내 필터를 청소하십시오.
- 4 새 필터를 흰색 부분이 먼지통을 향하도록 하여 거치대 안에 다시 넣으십시오. 거치대를 꼭 눌러서 아래 부분이 잘 맞도록 하십시오 (그림 27).
- 5 먼지 봉투가 들어있는 먼지 봉투 거치대를 제품에 다시 넣으십시오 (그림 25).

수퍼클린 에어 필터(특정 모델만 해당)

제품 뒤편에 있는 수퍼클린 에어 필터는 정전기로 충전되는 섬유를 이용하여 배출 공기에서 다량의 미세한 입자를 필터링합니다.
수퍼클린 에어 필터는 6개월마다 교체하십시오.

- 1 필터 커버를 여십시오 (그림 28).
- 2 오래된 필터를 빼내십시오.
- 3 제품에 새 필터를 끼우십시오 (그림 29).
- 4 필터 커버를 닫으십시오(‘찰칵’ 소리가 남) (그림 30).

물 세척이 가능한 수퍼클린 에어 HEPA 12 필터(특정 모델만 해당)

일부 모델의 경우 수퍼클린 에어 필터 대신 물세척 가능한 수퍼 클린 에어 HEPA 12 필터가 장착되어 있습니다. 이 필터는 배출 공기에서 나오는 0.0003mm 크기의 미립자를 99.5%까지 제거할 수 있습니다. 여기에는 일반 가정 먼지뿐 아니라 호흡기 알레르기를 유발하는 먼지 진드기 및 진드기 배설물과 같은 해로운 미세 해충도 포함됩니다.
물 세척이 가능한 수퍼 클린 에어 HEPA 12 필터는 6개월마다 청소하십시오. 이 제품은 최고 4번 까지 청소하여 사용할 수 있습니다. 이후에는 필터를 교체하십시오.

- 1 필터 커버를 여십시오 (그림 28).
- 2 물 세척이 가능한 HEPA 12 필터를 꺼내십시오.
- 3 HEPA 12 필터의 주름 잡힌 부분을 천천히 흐르는 뜨거운 물에 행구십시오.
 - 주름 잡힌 부분이 위를 향하고 물이 주름과 평행하여 흐르도록 필터를 잡으십시오. 필터를 기울어지게 잡아서 주름 사이의 먼지가 물에 씻겨 내려 가도록 잡으십시오 (그림 31).
 - 필터를 뒤로 돌려서 반대쪽 주름도 물에 씻으십시오 (그림 32).
 - 필터가 깨끗해질 때 까지 계속 씻으십시오.

물 세척이 가능한 필터를 브러시로 씻지 마십시오 (그림 33).

참고: 필터 세척을 통해 원래 색깔이 돌아오지는 않지만 필터링 기능은 회복됩니다.

- 4 필터를 조심스럽게 흔들어 물기를 털어내십시오. 필터를 진공 청소기에 다시 넣기 전에 최소 2시간 동안 말리십시오.
- 5 필터를 보관대 뒤에 끼우십시오. 필터의 필립스 로고가 왼쪽 상단 모서리에 보이도록 하십시오 (그림 29).
- 6 필터 커버를 닫으십시오(‘찰칵’ 소리가 남) (그림 30).

액세서리 주문

본 제품의 필터나 기타 액세서를 구하기 어려운 경우에는 필립스 고객 상담실로 문의 하거나 제품 보증서를 참조하십시오.

먼지 봉투 구매

- 필립스 클래식 S-bag ™ 합성섬유 먼지 봉투는 모델 번호 FC8021로 구매하십시오.
- 필립스 클리닉 S-bag ™ 강력한 필터 합성섬유 먼지 봉투는 모델 번호 FC8022로 구매하십시오.
- 필립스 냄새 제거 S-bag ™ 합성섬유 먼지 봉투는 모델 번호 FC8023으로 구매하십시오.

필터 구매

- 수퍼 클린 에어 필터는 모델 번호 FC8032로 구매하십시오.
- 물 세척이 불가능한 수퍼 클린 에어 HEPA 12 필터는 모델 번호 FC8044로 구매하십시오.
- 물 세척이 가능한 수퍼 클린 에어 HEPA 12 필터는 서비스 번호 4322 000 39090로 구매하십시오.

환경

- 수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 마시고 지정된 재활용 수거 장소에 버리십시오. 이런 방법으로 환경 보호에 동참하실 수 있습니다 (그림 34).

품질 보증 및 서비스

보다 자세한 정보가 필요하시거나, 사용상의 문제가 있을 경우에는 필립스전자 홈페이지 www.philips.co.kr 를 방문하시거나 필립스 고객 상담실로 문의하십시오. 전국 서비스 센터 안내는 제품 보증서를 참조하십시오. *(주)필립스전자: (02)709-1200 *고객 상담실: (080)600-6600(수신자부담)

문제 해결

이 란은 제품을 사용하면서 가장 일반적으로 경험하게 되는 문제와 그 해결 방법을 제시합니다. 발생한 문제를 아래 정보로 해결할 수 없는 경우에는 필립스 고객 상담실로 문의하십시오.

1 흡입력이 약합니다.

- A 먼지 봉투가 가득 차 있는지 확인하십시오.
필요한 경우, 교체형 먼지 봉투를 교체하거나 재사용이 가능한 먼지 봉투를 비우십시오 (일부 국가만 해당)
- B 필터 청소나 교체가 필요한지 확인하십시오.
필요한 경우 필터를 청소하거나 교체하십시오.
- C 흡입력 조절기가 최대 위치에 있는지 또는 손잡이의 조절기가 닫혀 있는지 확인하십시오.
- D 노즐, 연장관 또는 호스가 막혔는지 확인하십시오. (그림 35)
- 이물질 제거하려면 막힌 부분을 분리하여 반대 방향으로 가능한 멀리 연결하십시오. 진공 청소기의 전원을 켜서 막힌 부분에 공기가 반대 방향으로 통하도록 하십시오.

제조번호 부여기준: 필립스 전자 제품의 제조번호는 모두 4자리로 되어 있습니다. 앞의 두 자리는 연도를 의미합니다. 나머지 뒤의 두 자리는 생산된 주를 의미합니다. 주는 1년을 52주로 나누어 순차적으로 구분합니다.
(예: 0512 → 2005년 12번째 주에 생산
0504 → 2005년 4번째 주에 생산)

簡介

恭喜您購買本產品並歡迎加入飛利浦！請於 www.philips.com/welcome 註冊您的產品，來善用飛利浦提供的支援。

重要事項

在使用本產品前，請先仔細閱讀本使用手冊，並保留說明以供日後參考。

危險

- 請勿用來吸水或任何其它液體。請勿吸取易燃性物質，且請勿吸取尚未完全冷卻的灰燼。

警示

- 在您連接電源之前，請檢查本地的電源電壓是否與產品所標示的電源電壓相符。
- 當插頭、電線或產品本身受損時，請勿使用產品。
- 如果電線損壞，必須交由飛利浦、飛利浦授權之服務中心，或是具備相同資格的技師更換，以免發生危險。
- 本產品不適合供下列人士 (包括小孩) 使用：身體官能或心智能力退化者，或是經驗與使用知識缺乏者。他們需要有負責其安全的人員在旁監督，或指示產品的使用方法，方可使用。
- 請勿讓孩童將本產品當成玩具。
- 請勿將軟管、吸塵管或其他配件指向眼睛或耳朵，連接至使用中的吸塵器時，也不可將其放入口中。

警告

- 當您使用吸塵器來清除灰燼、細沙、石灰、水泥灰塵與類似物質時，集塵袋孔會逐漸阻塞，使得集塵袋已滿指示燈顯示集塵袋已滿。即使集塵袋並未全滿，也請更換可拆式集塵袋並且清空可重複使用的集塵袋 (請參閱「更換/清空集塵袋」單元)。
- 請勿在未安裝馬達防護濾網的時候使用本產品，否則可能會損壞馬達並縮短產品壽命。
- 請務必使用隨附的飛利浦 s-bag™ 合成集塵袋或重複使用型集塵袋 (僅限部份國家)。

電磁場 (EMF)

本飛利浦產品符合電磁場 (electromagnetic fields, EMF) 所有相關標準。若正確處理及依照本使用手冊之說明進行操作，根據現有之科學文獻來看，使用本產品並無安全顧慮。

使用前準備

軟管

- 1 連接軟管時，請將它插入吸塵器中 (1) 並依順時針方向轉動 (2)。(圖 1)
- 2 若要拆下軟管，請先依逆時針方向轉動 (1)，然後再將它從產品上拔出 (2)。(圖 2)

吸塵管

組合系統有兩種類型。本吸塵器採用其中一種類型。組合系統如下圖所示。

圓錐型結合機關 (限特定機型)

- 1 將吸塵管較窄的一端插入較寬的一端彼此相接，並連接到軟管的握把上，連接時稍微轉動。(圖 3)
- 2 若要拆解每一段吸塵管或將吸塵管與軟管的握把分開時，請稍微轉動並同時將它拉開。

按鈕結合機關 (限特定機型)

- 1 按下握把上的彈簧鎖定按鈕，將握把插入吸塵管，即可將吸塵管連接至軟管上的握把。將彈簧鎖定按鈕卡進吸塵管上的開孔 (會聽見「喀嗒」一聲)。(圖 4)
- 2 若要從軟管握把移除吸塵管，按下彈簧鎖定按鈕，然後將握把拔出吸塵管即可。

注意： 可使用相同方法連接、移除吸頭。

伸縮桿 (限特定機型)

- 1 將吸塵管調整至使用起來最舒適的長度。(圖 5)

Tri-Active 全方位三效合一吸頭 (限特定機型)

全方位三效吸頭是地毯及硬質地板專用的多用途吸頭。

- 兩側吸頭的側刷可吸除更多灰塵及髒污，讓您將家具和其他不易移動的物品清理得更乾淨。(圖 6)
- 吸頭前端開口可吸除更大碎屑。(圖 7)

- 1 若要清理硬質地板，請以腳推壓吸頭頂端的搖動開關。(圖 8)
 - ▶ 清潔地板的毛刷條從殼體內推出。在此同時，輪子會抬起，可防止刮傷地板又可加強移動性。
- 2 清潔地毯時，請再次推壓搖動開關。(圖 9)
 - ▶ 將毛刷條收進吸頭殼體內，輪子將會自動降下。

兩用吸頭 (限特定機型)

兩用吸頭可用於地毯或硬質地板。

- 1 若要清理硬質地板，請以腳推壓吸頭頂端的搖動開關 (圖 10)
 - ▶ 將毛刷條從吸頭殼體內推出，以清潔硬質地板。
- 2 清潔地毯時，請再次推壓搖動開關。(圖 11)
 - ▶ 將毛刷條收進吸頭殼體內。

細隙吸頭與小吸頭。

- 1 直接將縫隙吸頭 (1) 或小吸頭 (2) 連接至握把或吸塵管。(圖 12)

配件夾

- 1 將配件夾扣在吸塵管上。(圖 13)
- 2 將縫隙吸頭和小吸頭扣在配件夾上。

使用此電器

- 1 請將電線由產品拉出，並將插頭插入牆上插座。
- 2 用腳按下吸塵器頂部的開/關 (on/off) 按鈕，以開啟產品電源。(圖 14)
- 3 使用吸塵器時，您可以用以下裝置調整吸力：
 - 握把上的滑動鈕 (限特定機型) (圖 15)
 - 吸塵器頂端的旋鈕 (限特定機型) (圖 16)
- 4 若您想要暫停片刻，請將吸頭上的突出物插入安置槽，以將吸塵管固定為便於使用的位置。(圖 17)

收藏

- 1 請關閉產品電源，並將插頭從牆上插座拔下。
- 2 按下收線鈕，將電源線收回。(圖 18)

- 3 將產品直立起來，將吸頭突出部份插入儲存槽，讓吸頭與產品相連接。(圖 19)
- 4 在您收納全方位三效吸頭時，請務必將它設為地毯設定。請避免側邊毛刷彎曲變形。(圖 9)

更換/清空集塵袋

更換拋棄式集塵袋或清空可重複使用的集塵袋之前，請務必拔除電源插頭。

更換拋棄式集塵袋

- 如果集塵袋已滿指示燈的顏色長時間改變(換言之，即使吸頭沒有貼緊地板的情況下)，請立即更換集塵袋。(圖 20)

- 1 請將蓋子往上拉，掀開蓋子。(圖 21)
- 2 將集塵袋支托架從本產品中提起。(圖 22)

請確定從吸塵器中提起集塵袋時開口是向上的。

- 3 拉著紙板拉片，將已滿的集塵袋從支托架中移除。(圖 23)
▶ 移除集塵袋時，集塵袋會自動封口。
- 4 將新集塵袋的紙板前端儘可能套入集塵袋支托架上的兩個狹槽中。(圖 24)
- 5 將集塵袋支托架重新裝入吸塵器。(圖 25)

注意：如果沒有裝入集塵袋，您將無法關上蓋子。

清空可重複使用的集塵袋 (僅限部份國家)

在某些國家，吸塵器也擁有可重複使用的集塵袋，可供使用並且重複清空。您可以使用重複使用的集塵袋代替拋棄式的集塵袋。

若要拆卸或安裝可重複使用的集塵袋，請依照「更換拋棄式集塵袋」的更換步驟進行即可。

清空可重複使用的集塵袋：

- 1 將夾子朝集塵袋的側邊滑動。
- 2 將集塵室中的內容物搖動倒入垃圾桶中。
- 3 若要關閉集塵袋，請將夾子朝集塵袋下緣滑動。

濾網的清潔與保養

在清潔或更換濾網之前，請務必拔除電源插頭。

永久馬達防護濾網

每次更換集塵袋時，請清潔永久馬達防護濾網。

- 1 將集塵袋支托架連同集塵袋一起一併拆除。(圖 22)
- 2 將馬達防護濾網支托架從產品中移除，將濾網支托架取出。(圖 26)
- 3 在垃圾桶上抖動濾網。
- 4 將濾網重新裝入支托架上，白色那一面朝向集塵室。將支托架用力往下壓，以確定底部妥善安裝至定位。(圖 27)
- 5 將集塵袋支托架連同集塵袋一起一併裝回本產品中。(圖 25)

高效微塵濾網 (限特定機型)

高效微塵濾網位於吸塵器的後方，負責利用它的靜電纖維對排出的空氣進行過濾，去除大部分的小型塵粒。

高效微塵濾網每六個月應更換一次。

- 1 打開濾網罩。(圖 28)
- 2 移除舊濾網。
- 3 將新濾網插入產品中。(圖 29)
- 4 關閉濾網罩(會聽見「喀嗒」一聲)。(圖 30)

非可水洗超淨空氣 HEPA 12 抗敏濾網 (限特定機型)

除了高效微塵濾網之外，某些機型配有可水洗超淨空氣 HEPA 12 抗敏濾網。這個濾網可過濾掉排放到空氣中 99.5% 小至 0.0003 公釐的所有粒子。這不只包括一般住家灰塵，還有肉眼看不見的有害寄生蟲，如塵 及其排泄物，皆為常見的呼吸道疾病過敏原。超淨空氣 HEPA 12 抗敏濾網應每六個月清潔一次。可水洗超淨空氣 HEPA 12 抗敏濾網最多可清洗四次。清洗四次之後請更換濾網。

- 1 打開濾網罩。(圖 28)
- 2 取出可水洗 HEPA 12 抗敏濾網。
- 3 在熱水龍頭下清洗 HEPA 12 抗敏濾網皺摺面。
 - 握住濾網將皺摺面朝上，讓水流與皺摺呈平行方向。傾斜握住濾網，讓水流沖洗皺摺內部的灰塵。(圖 31)
 - 將濾網旋轉 180°，讓水流沿著皺摺面的反方向沖洗。(圖 32)
 - 持續進行，直到濾網洗淨。

請勿使用刷子清潔可水洗濾網。(圖 33)

注意：清潔濾網無法恢復濾網原本的顏色，但可以恢復濾網效能。

- 4 仔細地甩乾濾網表面的水份。將濾網放回吸塵器之前，至少風乾濾網 2 小時。
- 5 將濾網裝在托架後。請確定在濾網的左上角可以看見飛利浦的標誌。(圖 29)
- 6 關閉濾網罩(會聽見「喀嗒」一聲)。(圖 30)

訂購配件

如果您在購買集塵袋、濾網或其他本產品配件上有任何困難，請連絡您所在國家/地區的飛利浦顧客服務中心，或查詢全球保證書。

訂購集塵袋

- 飛利浦 Classic s-bag™ 合成集塵袋型號為 FC8021。
- 飛利浦醫療級 Clinic s-bag™ 高效過濾合成集塵袋型號為 FC8022。
- 飛利浦抗臭 s-bag™ 合成集塵袋型號為 FC8023。

訂購濾網

- 高效微塵濾網型號為 FC8032。
- 非可水洗超淨空氣 HEPA 12 抗敏濾網型號為 FC8044。
- 可水洗超淨空氣 HEPA 12 抗敏濾網型號為 4322 000 39090

環境保護

- 電器壽命結束時請勿與一般家庭廢棄物一併丟棄。請將該產品放置於政府指定的回收站，此舉能為環保盡一份心力。(圖 34)

保固與服務

若您需要相關資訊或有任何問題，請造訪飛利浦網站 www.philips.com，或連絡您當地的飛利浦客戶服務中心(您可以在全球保證書上找到連絡電話)。如果您當地沒有客戶服務中心，請洽詢當地飛利浦經銷商，或與飛利浦小家電及個人護理用品部門聯繫。

故障排除

本單元概述您使用本產品時最常遇到的問題。如果您無法利用以下資訊解決您遇到的問題，請聯絡您所在國家/地區的顧客服務中心。

1 吸力不足。

A 請檢查集塵袋是否已滿。

必要時，請更換拋棄式集塵袋或清空可重複使用的集塵袋 (僅限部份國家)。















B 請檢查濾網是否需要清潔或更換。

必要時，請清潔或更換濾網。

C 請檢查吸力旋鈕是否設定在最大位置，和/或手把上的撥環是否關閉。

D 請檢查吸頭、吸塵管或軟管是否有阻塞。(圖 35)

- 若要去除阻塞物，請拆除阻塞的部分，並將它以相反的方向 (盡可能地) 連接。打開吸塵器，使空氣以相反方向強制吹出阻塞的部分。





www.philips.com



Mixed Sources

Product group from well-managed
forests and other controlled sources
www.fsc.org Cert no. CU-COC-413596
© 1996 Forest Stewardship Council

4222.003.3112.5