



P3160

©2023 Bestway Inflatables & Material Corp.

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten/Tutti i diritti riservati

Trademarks used in some countries under license from/

Marques utilisées dans certains pays sous la licence de/

Marcas comerciales utilizadas en algunos países bajo la licencia de/

Die Warenzeichen werden in einigen Ländern verwendet unter Lizenz der/

Marchi utilizzati in alcuni paesi concessi in licenza a

Bestway Inflatables & Material Corp., Shanghai, China

Manufactured, distributed and represented in the European Union by/

Fabriqués, distribués et représentés dans l'Union Européenne par/Fabricado, distribuido y representado en la Unión Europea por/

Hergestellt, vertrieben und in der Europäischen Union vertreten von/Prodotto, distribuito e rappresentato nell'Unione Europea da

Bestway Europe S.p.a., Via Resistenza, 5, 20098 San Giuliano Milanese (Milano), Italy

Distributed in Latin America by/Distribué en Amérique latine par/Distribuido en Latinoamérica por/Distribuido na América Latina por

Bestway Central & South America Ltda, Salar Ascotan 1282, Parque Enea, Pudahuel, Santiago, Chile

Distributed in Australia & New Zealand by **Bestway Australia Pty Ltd, Unit 2/98-104 Carnarvon St Silverwater, NSW 2128, Australia**

Tel: Australia: +61 2 9037 1388; New Zealand: +0800 142 101

Distributed in United Kingdom by **Bestway Corp UK Ltd, 8 Wentworth Road, Heathfield Industrial Estate, Newton Abbot, Devon, TQ12 6TL**

Exported by/Exporté par/Exportado por/Exportiert von/Esportato da

Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

www.bestwaycorp.com

OWNER'S MANUAL

Air Mattress with Built-in Rechargeable Pump

6716S/6716T

WARNING:

1. If instruction is missed, please contact with Bestway or search it in website: www.bestwaycorp.com
2. Do not use the pump continuously more than 5 minutes. It can only be used again after at least 15 minutes of cooling.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
4. The appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
5. The battery must be removed from the appliance before it is scrapped.
6. The appliance must be disconnected from the supply mains when removing the battery.
7. This appliance contains battery that is non-replaceable.
8. The battery is to be disposed of safely. The end customer must not dispose the removed battery in household waste. The end customer can return the removed battery to the retailer store where he purchased the product or to municipal or other public collection points.
9. Content: air mattress, USB charging cable, repair patch, manual.

NOTICE: READ THE INSTRUCTIONS COMPLETELY AND SAVE THESE INSTRUCTIONS. RETAIN THIS BOOKLET FOR FUTURE REFERENCE.

CAUTION: THERE ARE RISKS WHEN YOU USE THE ARTICLE IN THE OPEN AND/OR AS WATERCRAFT. KEEP

AWAY FROM FIRE.

10. Max load: 300 kg / 661 lbs

NOTE: Do not exceed the maximum load recommended, or the airbed will be damaged and even explode.

NOTE: The product is not intended for commercial use.

DISPOSAL



Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

If the product is out of service, please cut it and dispose according to your local council. Dispose the package carefully and thoughtfully. Do not litter. To be a good citizen and dispose of litter in an environmentally manner.


TECHNICAL SAFETY INSTRUCTIONS

- One lithium cell 2000mAh rechargeable battery is inside the pump. Please charge the battery for at least 4 hours before first use.
- Please use a DC 5V Max 2A adaptor with safety certification for this pump.
- When charging, the light turns red. The green light will come when the product is full of battery.
- The pump must be stored in a dry location at 15°C - 45°C (59°F - 113°F) temperature. If the pump is not used for more than 6 months, the battery will discharge. The battery must be charged every 3 months.
- Please use the product and charge the pump at 15°C - 40°C (59°F - 104°F) temperature and avoid exposing it to powerful sunlight.
- **NOTE:** Drawings are for illustration purpose only. May not reflect actual product. Not to scale.

BUTTON FUNCTION DESCRIPTION




On / Off button: Press the button to start or stop inflation.







1.1





1.2



1.3




1.4







2.1




2.2




3.1



3.2




3.3



15°C/59°F

4.1




4.2



4.3



4.4



4.5



PVC

